

SurX4.0 Software

User Manual

Copyright ©KOLIDA Surveying Instrument CO.,LTD.

*All Rights Reserved

CONTENT

| | |
|--|----|
| Chapter 1 Software Introduction | 1 |
| 1.1 Software introduction | 1 |
| 1.2 Software interface..... | 1 |
| 1.3 Software installation and uninstallation | 3 |
| Chapter 2 Quick Start Guide..... | 5 |
| Chapter 3 Project..... | 8 |
| 3.1 Project Manager | 8 |
| 3.2 File Manager | 9 |
| 3.3 Coordinate System | 11 |
| 3.4 Calibrate Point..... | 15 |
| 3.5 Coordinate point Library | 18 |
| 3.6 File Export..... | 21 |
| 3.7 Scan | 22 |
| 3.8 Cloud Settings..... | 23 |
| 3.9 Software Settings | 23 |
| 3.10 Software About | 25 |
| Chapter 4 Device | 27 |
| 4.1 Communication | 27 |
| 4.2 Rover mode | 28 |

| | |
|---------------------------------------|----|
| 4.2.1 Rover-RTK Network | 30 |
| 4.2.2 Rover-Internal Radio | 31 |
| 4.2.3 Rover-External Radio | 32 |
| 4.2.4 Rover-Bluetooth Data Link | 32 |
| 4.3 Base mode | 33 |
| 4.3.1 Base-RTK Network | 35 |
| 4.3.2 Base-Internal Radio | 36 |
| 4.3.3 Base-External Radio | 37 |
| 4.4 Static mode | 37 |
| 4.5 Information | 40 |
| 4.6 Calibrate Sensor | 40 |
| 4.7 Device Register | 42 |
| Chapter 5 Survey | 43 |
| 5.1 Point Survey | 43 |
| 5.2 Detail Survey | 50 |
| 5.3 CAD | 51 |
| 5.4 Point Stakeout | 54 |
| 5.5 Line Stakeout | 57 |
| 5.6 Stake road | 62 |
| 5.7 Stake road by point | 64 |

| | |
|--|-----|
| 5.8 Stake road by cross section | 67 |
| 5.9 Stake road by bridge section | 69 |
| 5.10 Conical Slope Stakeout | 72 |
| 5.11 Electric Lines Survey | 74 |
| 5.12 Tower Stake | 80 |
| 5.13 Elevation Control | 82 |
| 5.14 Curve Stakeout | 84 |
| 5.15 Existing Stakeout | 86 |
| 5.16 Railway Stakeout | 88 |
| 5.17 Survey Range Settings | 92 |
| 5.18 Layers Settings | 94 |
| Chapter 6 Tools | 96 |
| 6.1 Site Calibration | 96 |
| 6.2 Coordinates Converter | 98 |
| 6.3 Angle Converter | 99 |
| 6.4 Perimeter and area | 99 |
| 6.5 COGO Calculation | 101 |
| 6.5.1 Coordinate inverse calculation | 101 |
| 6.5.2 Point line calculation | 102 |
| 6.5.3 Vector | 102 |

| | |
|---|-----|
| 6.5.4 Two Lines Angle..... | 103 |
| 6.5.5 Intersection calculation..... | 103 |
| 6.5.6 Resection..... | 104 |
| 6.5.7 Forward intersection..... | 104 |
| 6.5.8 Coordinate positive calculation..... | 105 |
| 6.5.9 Offset point calculation..... | 105 |
| 6.5.10 Equal point calculation..... | 106 |
| 6.6 Calculator..... | 106 |
| 6.7 External Radio configuration (not support KOLIDA receiver now)..... | 107 |
| 6.8 Station Refresh..... | 110 |
| Chapter 7 Total Station..... | 112 |
| 7.1 Communication..... | 112 |
| 7.2 Height..... | 112 |
| 7.3 Measure Mode..... | 113 |
| 7.4 Orientation setup..... | 121 |

Chapter 1 Software Introduction

1.1 Software introduction

SurvX4.0 is a GNSS surveying and mapping software is Based on years of accumulating market experience, in combination with the international mainstream of surveying and mapping data acquisition function of the software, integrating RTK control, GIS data collection and road design and layout into one role. The main feature of the software is very outstanding graphic interaction, very powerful function and humanizes operation process. This manual mainly introduces all the menu functions and the field operation procedure of the SurvX software.

SurvX4.0 main menu contains four settings: [Project], [Device], [Survey], [Tools].

[Project] It mainly manages project operation. Its main menu includes Project Manager, File Manager, Coordinate System, Calibrate Point and other items. It can create new project in project management, set coordinate parameters in coordinate system and check points collected in survey in coordinate library.

[Device] It mainly sets operation mode and check receiver's information after connecting to receiver. Its main menu includes Communication, Rover, Base, Static and other items. After successfully connecting to receiver through Bluetooth in Communication and choosing base, rover or static operation mode, it can check operation information and datalink status of receiver in Work Mode Status. If it needs to calibrate receiver, it should enable Tilt Survey and then calibrate E-Bubble and Magnetic in Calibrate Sensor.

[Survey] Its main menu includes Point Survey, Detail Survey, CAD, Point Stakeout, Line Stakeout, Stake Road, Electric Lines Survey and other items.

[Tools] It includes various calculation methods and External Radio Configuration, mainly containing Site Calibration, Coordinates Converter, Angle Converter, Perimeter and Area, COGO Calculation, Calculation, External Radio Configuration, Volume Calculation and Station Refresh.


1.2 Software interface

Main interface: On Android device installing and running this software, if there exists existing project in it, it would directly enter into main interface, as shown in Figure 1.2-1. Sliding to the left in turn will bring you to the next navigation menu interface.

Main interface title bar:

Title bar mainly displays current project name, solution states after connection with receiver and some quick function.

K: About software. Press to enter into interface as shown in Figure 1.2-2. It can check software copyright information, update software, activate software and submit your feedback about the software.

: Communication. Press to enter into interface as shown in Figure 1.2-3 and connect to receiver. This icon shows two states: blue for successful connection with receiver, and white for no connection.




Figure 1.2-1




Figure 1.2-2





Figure 1.2-3

: Positioning information. After connection with receiver, press to enter into interface as shown in Figure 1.2-4 and it can check current positioning information. Press Base below the screen as shown in Figure 1.2-5 and it can check base information, and then press Save to save current base coordinate. Press Sate Map below the screen as shown in Figure 1.2-6, and it can check coordinate reference position with different colors representing different coordinate system and upper left circles showing satellite system represented by each color. Press Sate Info below the screen as shown in Figure 1.2-7, and it shows current found satellites' number, L1\L2\L5 SNR, Elevation Angle, Azimuth Angle and other information. Press Sate SNR below the screen as shown in Figure 1.2-8, and it can check satellites' L1\L2\L5 SNR illustrated by bar graph.



Main interface setting. As shown in Figure 1.2-9, it can set interface style to List or Grid. Other options show whether to enable corresponding functions in survey interface, which are turned on by default.




Figure 1.2-4




Figure 1.2-5




Figure 1.2-6




Figure 1.2-7




Figure 1.2-8




Figure 1.2-9

1.3 Software installation and uninstallation

Software installation:

(1) Download the Android SurvX4.0 installation package (*.apk).

(2) Copy the installation package to Android device. Find the installer in File Manager in

Android device as shown in Figure 1.3-1. Click the installer and pops up installation dialog box as

shown in Figure 1.3-2. Click Install and pops up dialog box for preferred installation location as shown in Figure 1.3-3, and installation completion dialog box will pop up shortly as shown in Figure 1.3-4. Press Done to return to device desktop and press Open to run SurvX software.




Figure 1.3-1




Figure1.3-2




Figure1.3-3




Figure1.3-4

Uninstallation:

Method 1: long press software icon on the desktop and drag it to Uninstall box. It pops up dialog box saying whether to uninstall it. Press Uninstall to complete uninstallation.

Method 2: press Settings → find SurvX 4.0 in Apps as shown in Figure 1.3-5. Press SurvX → press Uninstall as shown in Figure 1.3-6 . It pops up dialog box saying whether to uninstall as shown in Figure 1.3-7, and press Uninstall to complete uninstallation.




Figure1.3-5




Figure 1.3-6




Figure 1.3-7

Chapter 2 Quick Start Guide

Taking operation mode as handheld network with connection with RTK as example, this chapter introduces the steps of quickly connecting to receiver and performing survey. Detailed steps are as follows:

1. Preparation

An RTK receiver, a P9A handheld (or other Android handheld) with SurvX4.0 installed and network.

2. Create new project

Run SurvX4.0 software, press [Project] -> [Project Manager] -> [New], create a new project, enter project name, and choose coordinate parameter type. Other items are additional information which can be left blank. Press [OK] and the screen jumps to interface of coordinate system parameters. In China, Ellipsoid Parameter is Beijing54 by default, and Projections Parameter is Gauss Kruger. You can set the coordinate system according to the actual situation.

3. Connect to receiver and set operation mode

Press [Device] -> [Communications], choose device type as **Kolida** and communication mode as Bluetooth, press [Search] to find receiver in Bluetooth Device List, press [Connect], and then pops up connection progress box which indicates successful connection.

Press [Device] -> [Rover], select data link as [Handheld network], set up IP and port of CORS server, and acquire and select access point. Other options can set as default values. Press [Apply] to finish operation mode setting. Return to main interface to see if there is a fixed solution.

4. Calibrate

- Calibrate Point

In fixed solution state, press [Project] -> [Calibrate Point] -> [Marker Point Calibration], input known coordinates, set antenna parameters of current coordinates of the base station, and press [Calculate] to get calibration parameters.

- Site calibration

With a new surveying area, site calibration is required at the first if you want the measured points match the known points.

Here are general conditions to do site calibration: assuming that you use the known points A, B and C to calculate the transformation parameters, their GPS original records of WGS-84 coordinates and local coordinates should be recorded firstly. There are two ways to obtain the GPS original records of WGS-84 coordinates at points A, B and C: one is setting up static control network and recording coordinates by post-processing software; the other one is recording coordinates when GPS rover station in fixed solution without any parameters working.

Press [Tools] -> [Site Calibration], input the known points (select from Points Library or input manually) and WGS84 ellipsoid original coordinates (obtain current GPS data and select from Points Library or input manually), choose whether use Horizontal Control and Vertical Correction, and press [OK] to complete input of transformation parameters. And press [Calculate] to obtain GPS Parameters Reports in Site Calibration interface.

5. Survey

Press [Survey] -> [Point Survey]/[Text Survey], taking “topographic point” as example, press point types icon, choose Topo Point, press setting to set up topo point recording limit(Fixed solution, H: 0.05, V: 0.1, PDOP: 3.0, Delay: 5, Average GPS Count: 1), and press collect points icon lower right corner or collect points shortcut key on handheld to complete target points' acquisition and preservation.

6. Data import and export

1) Data import

Copy the data file needs to import to SurvX folder on handheld, press [Project] -> [Coordinate point Library] ->[Import], select File Format, Angle format and Property type, find the data file and press [OK] to import data file.

2) Data export

Press [Project] -> [Fil Export], select data files, file format, angle format and point type, choose exported file storage path and press [Export] to export data file.

Chapter 3 Project

In software main interface, press [Project] to display submenu as shown in Figure 3-1. Included in Project submenu are Project Manager, File Manager, Coordinate System, Calibrate Point, Coordinate Point Library, File Export, Scan, Cloud Settings, Software Settings and Software About.

SurvX4.0 manages data in the form of engineering documents, in which way all operation is controlled in a project. Every time open SurvX4.0, the software will automatically invoke engineering documents used last time. Under general circumstances, every time you begin to measure an area, it must create a project file matched with current project coordinates, and the file format should be *.GSW. After the project has been created, in the device storage disk the software will create a file in which all data will be saved, whose file name is same with the project.




Figure 3-1




Figure 3.1-1




Figure 3.1-2

3.1 Project Manager

Press [Project] -> [Project Manager] to enter into interface as shown in Figure 3.1-1.

Project Path shows current project's storage position, which can be pressed to change as shown in Figure 3.1-2. If the workload is large in survey, please choose sufficient storage position to save project.

Press [New] to create a new project as shown in Figure 3.1-3. Input Project Name (required, defaults to created date), Operator, Device and Notes, select Coordinate systems parameters type

(local parameters/ RTCM1021~1027 parameters/CORS encrypt parameters; please see Section 6.1 for more details), press [OK] to set up coordinate systems parameters, and press [OK] to complete new project creation.

If you need to check or modify current project’s information, press [Details] as shown in Figure 3.1-4 to enter into Project Details interface.

If you need to open other projects, select the project and press [Open] to open it and use it as current project by default.

If you need to delete project, select the project and hold, press [Delete] as shown in Figure 3.1-5, press [OK] in Prompt to delete project. Current operating project cannot be deleted.




Figure 3.1-3




Figure3.1-4




Figure3.1-5

3.2 File Manager

This function can be used in a project where there is too much data or when you want to distinguish between two different coordinate point libraries.

Press [New] to enter into interface as shown in Figure 3.2-1, and there pops up interface as shown in Figure 3.2-2. Create a data file to store the recorded survey data and the new file defaults to data file for current project storage record. The file name defaults to current data file name - 1, file suffix for *. PD. The new document belongs to current project.




Figure 3.2-1




Figure 3.2-2

Press [Import] to enter into interface as shown in Figure 3.2-3, choose file path, and it can import files with *.RTK as suffix. Document name defaults to current data file name-2 (automatically accumulate). If a same file is imported twice, there will pop up a prompt as shown in Figure 3.2-4 saying “Current data file exists. Include backup data into current data file?” If the data format of the imported *.RTK file is abnormal, there will pop up a prompt saying “RTK file import failed, please check!”

Select a file in the file list, press [Delete] as shown in Figure 3.2-4, and press [OK] to delete the data file.

When a project has multiple data files, select the data file in the data list and press [Open] to switch between different data files.




Figure 3.2-3




Figure 3.2-4




Figure 3.2-5

3.3 Coordinate System

1. Local coordinate parameters

Press [Project] - [Coordinate System] to enter into interface as shown in Figure 3.3-1. All options can be pressed to set up the parameter.

Press [Export] and choose [Local Disk] as shown in Figure 3.3-2 to save system data to the specified path as shown in Figure 3.3-3. It can also encrypt the file by setting up Expiry Date, General Password (data can't be viewed before expiry date) and Advance Password (data can be viewed before expiry date). Press [Export] and choose [QR Code] to share current coordinate system parameters.

Press [Use existing] as shown in Figure 3.3-4, choose [Local Disk] to apply coordinate system parameters stored in local disk. Parameter files are in two formats: *.SP and *.EP. Choose [QR Code] to scan QR code to apply coordinate system.

Ellipsoid Parameter: as shown in Figure 3.3-5, it can set up Target ellipsoid. Target ellipsoid supports defined or custom parameters. With custom ellipsoid, it needs to set up Semimajor axis and Reciprocal of flattening 1/f, which should be consistent with the ellipsoid used for parameter calculation.




Figure 3.3-1




Figure 3.3-2




Figure 3.3-3




Figure 3.3-4




Figure 3.3-5




Figure 3.3-6

Projections Parameter: as shown in Figure 3.3-6, the frequently-used projections mode is Gauss Kruger, and after connecting to the device the Central Meridian can be acquired automatically via a press on or manually via inputting the exact value. Common projections parameters are set up as followed: False Northing-0, False Easting-500000, Scale Factor-1, Projection Height-0 at low altitudes and change it as needed at high altitudes, Latitude of Origin-0.

ITRF Parameter: ITRF is the International Earth Reference Framework. To enable ITRF conversion, it needs to choose Conversion type, input The target of epoch and enable/disable Input velocity. If enabling Input velocity, it needs to input values for Vx, Vy and Vz as shown in Figure 3.3-7.




Figure 3.3-7




Figure 3.3-8




Figure 3.3-9

Seven-Parameter: as shown in Figure 3.3-8, it is used to perform Space rectangular coordinate transformation within two different ellipsoids. In general, at least three known points and six groups of XYZ coordinate values in two different space rectangular coordinate system are required to calculate the seven unknown parameters. With these seven parameters, by seven parameter equations, the XYZ coordinate value of a point in one space rectangular coordinate system can be converted to the XYZ coordinate value of another space rectangular coordinate system. Seven-parameter model includes seven values:

- (1) three coordinate shifts ($\Delta X, \Delta Y, \Delta Z$), i.e. the difference between the coordinates of the two coordinate systems;
- (2) rotation angles of three coordinate axes($\Delta \alpha, \Delta \beta, \Delta \gamma$), the XYZ axis of two spatial rectangular coordinate systems can be recombined by rotating the three coordinate axes in order to specify the Angle;
- (3) scale K, i.e. the length ratio of a same line in two space rectangular coordinate systems realizing scaling. Generally, K is almost equal to 1.

Four-Parameter/Horizontal Adjustment: as shown in Figure 3.3-9, in general at least two known points and four pairs of XY coordinate values in two different space rectangular coordinate system are required to calculate the four unknown parameters. With these four parameters, by four parameter equations, the XY coordinate value of a point in one space rectangular coordinate system can be converted to the XY coordinate value of another space rectangular coordinate system.




Figure 3.3-10




Figure 3.3-11

Vertical Control Parameter: GPS elevation system is earth height (ellipsoid height) while elevation system usually used in survey is normal height. As a result, height measured by GPS needs to correct to use, and Vertical Control Parameter is for this matching. Set up the parameter as shown in Figure 3.3-10.

Vertical Adjustment Parameter: elevation transformation model of Trimble TGO software includes five parameters: Adjustment Constant, North Slope, East Slope, Original Northing and Original Easting, as shown in Figure 3.3-11.

Geoid File: as shown in Figure 3.3-12, the essence of geoid measurement is to measure height difference between two points on the ground, and then calculate the height of unknown points through the height of known points. It's a way to calculate height of a point directly by height difference. SurvX4.0 imports geoid file (so far supports *.GGF, *.SGF, *.UGF formats), and select transformation mode (Bilinear/Quadratic/ Bi Cubic Spline) to obtain accurate height of coordinate.

Local Offsets: a known point is required to calculate the local offsets. This parameter is used in a small range, and its accuracy is determined by operating range and decreases with the increase of operating distance.




Figure 3.3-12




Figure 3.3-13

2. RTCM1021~1027 parameter

RTCM1021~1027 is a way to send coordinate system parameter via differential data. When coordinate system parameters type is set up as RTCM1021~1027 parameters in project creation,

the software analyses coordinate parameters from received differential data. In this mode, parameters don't support manual set up as shown in Figure 3.3-13.

3. CORS encrypt parameter

CORS encrypt parameter is mainly used by CORS merchants, which can be used when merchants provide coordinate parameters and want to keep secret. When the CORS merchants provide this encrypt parameter to user, user does not know the specific coordinate system parameters.

3.4 Calibrate Point

Press [Project] -> [Calibrate Point] to enter into interface as shown in Figure 3.4-1. There're 2 ways to calibrate: one is Base Point Calibration, with base coordinate before and after station change to perform calibration; the other is Marker Point Calibration, with the coordinates of the points collected before and after the station change.




Figure 3.4-1




Figure 3.4-2




Figure 3.4-3

Base Point Calibration steps as follows:

(1) Press [Base Point Calibration] to enter interface as shown in Figure 3.4-2.

(2) Input the known points, i.e. coordinate before base change. There are two ways to input coordinate: one is to select existing base coordinate from Points Library, the other one is to directly input base coordinate x, y, h before base change. Press [Antenna Parameters] to set antenna parameters as shown in Figure 3.4-3.

(3) Input Antenna Measured Height, set Antenna Measurement Type (Vertical height, Height to phase center, Slant height, Slant height to altimetry), and Antenna Type is automatically selected according to current connected receiver, and press [OK] to return to Base Point Calibration interface.

(4) Press [Calculate] to check calculation result as shown in Figure 3.4-4. Press [Apply] and it would directly apply the calculation result. If the calculation result is in red font, it means translation parameter over range (longitude difference over 1 degree or latitude difference over 1 degree or height difference over 1000), in which press [Apply] and there would pop up a prompt as shown in Figure 3.4-5 saying “High residuals error! Apply local offsets to current project?”. If press [Apply] it would jump to Local Offsets interface as shown in Figure 3.4-6 to display the result. Press return key upper right and pops up prompt to ask whether to apply calculation result, and after selection it returns to Base Point Calibration interface.

Note: Base Point Calibration only can used in fixed solution.




Figure 3.4-4




Figure 3.4-5




Figure 3.4-6

Marker Point Calibration steps as follows:

(1) Press [Marker Point Calibration] as shown in Figure 3.4-7, input Known Point Coordinates (x, y, h), and press [Current WGS84 Coordinates] to obtain current WGS84 coordinates. Press [Measure] to enter interface as shown in Figure 3.4-8, set Saved Conditions as shown in Figure 3.4-9 and set Antenna Parameters, and then press [OK] to acquire current WGS-84 coordinates.

(2) Press [Calculate] as shown in Figure 3.4-10 to get calculate result. If the calculation result is in red font, there would pop up a prompt saying “High residuals error! Apply local offsets to current project?”. Press return key upper right and pops up prompt as shown in Figure 3.4-11, press [No] to return to Calibrate Point interface while press [Apply] to return to Calibrate Point interface and display calibration result as shown in Figure 3.4-12.




Figure 3.4-7




Figure 3.4-8




Figure 3.4-9




Figure 3.4-10




Figure 3.4-11




Figure 3.4-12

Calibrate Point performs on the basis of fixed solution and opened transformation parameters. The essence is three parameters using a common point to calculate two different coordinates, also known as the calibration parameter in the software. This function can be used in the following situations:

1. When with [Use Current Coordinates] in the startup mode parameters of base, and the base have been restarted or its position has been moved, the rover should calibrate point.

2. When the user knows the conversion parameter of the work area, base could be set up at any place. Please input the conversion parameter, and the rover should calibrate point.

Note: The calibrate point parameters will not refresh the current point coordinates in the library. When display the current point coordinates, it will also display the calibrate point parameters, the subsequent measurement of the coordinates will be corrected by the calibrate point parameters. Transformation parameters by calculating the parameters of the library will refresh the current coordinates of the point. The WGS-84 coordinates of the measurement point are converted to local coordinates by conversion parameters.

3.5 Coordinate point Library

Press [Project]-> [Coordinate point Library] to enter into interface as shown in Figure 3.5-1.




Figure 3.5-1




Figure 3.5-2




Figure 3.5-3

The Coordinate point Library is used to uniformly manage all types of coordinate points. It can input coordinate points used in survey, which offers convenient to invoke in Point Stakeout. It can enter point name or code in the lookup to quickly search for coordinate points. It contains Add, Edit, Details, Import, Delete, Options and Recovery operation.

Press [Add] to enter into interface as shown in Figure 3.5-2. Coordinate points can be divided into Local Coordinates and Geodetic Coordinates according to Coordinate type, and Assistant

point, Control point, Input point and Stakeout point according to Property type. After selecting Coordinate type and Property type, input the point name and horizontal coordinates (x, y, h) or longitude and latitude coordinates and code to add a new point.

Select any coordinate point and press [Edit] as shown in Figure 3.5-3. It can edit Name, Code, Photo And Sketch and Antenna Parameters, and press [OK] to complete edition. Inputted point can be edited its coordinate while measured point can only edit Name and Code.

Press [Details] as shown in Figure 3.5-4 to check the point name, code, longitude and latitude coordinates, horizontal coordinates (x, y, h), point type and other information.

Press [...] as shown in Figure 3.5-5 to import, delete and set options of points.




Figure 3.5-4




Figure 3.5-5




Figure 3.5-6

Press [Import] as shown in Figure 3.5-6, select File Format, Property type and whether to Preview and press [OK]. Select file path and find the file and press [OK] as shown in Figure 3.5-7 to preview the data. If the data is correct, then press [OK] to import coordinates. File Format includes Measurement data file (not support to preview), Cass format, Geodetic coordinates format, Local coordinates format, COT format, NETCAD format and user-defined format (press Format Manage to create user-defined format).

Press [Format Manage] to enter interface as shown in Figure 3.5-8, press [New] to enter interface as shown in Figure 3.5-9, input Format name, select Field delimiter (, @ Space) and Extension name (dat, csv, txt), select Custom format description (to select [Point Name]) and press

[Add] means format includes point name), press [OK] to return to interface as shown in Figure 3.5-8 and created data formats list in it. Press upper left return key to return to interface as shown in Figure 3.5-6 and it can see user-defined format in File Format.




Figure 3.5-7




Figure 3.5-8




Figure 3.5-9

Press [Delete] as shown in Figure 3.5-10 to delete one or more points. Select points by press on points or press on Select All below, press [Delete] and [OK] in the pop-up prompt to delete selected points. Deleted points can be recovered with [Recovery] as shown in Figure 3.5-11. Select points need to recover and press [Recovery], and then the selected points would be displayed in Coordinate point Library. Long press point will also enter the bulk delete mode.




Figure 3.5-10




Figure 3.5-11












Figure 3.5-12

Press [Options] as shown in Figure 3.5-12. Enabling the point types need to display can filter those types disabled. It includes point types: Auxiliary Point , Survey Point , Control Point , Input Point , Calculate Point , Stake Point , Screen Point , Base Point .

3.6 File Export

1. Data file export

Press [Project] -> [File Export] to enter into interface as shown in Figure 3.6-1. Data file export is to export measurement data file into the data format that user needs to graph.



Figure 3.6-1




Figure 3.6-2




Figure 3.6-3

It can export in specified format or user-defined format. It requires to select data file and file format. File Format includes user-defined formats, AutoCAD file format (*.DXF), GoogleEarth file format (*.KML), Cass format, raw survey data (*.CSV) and other formats. Press [Export], choose file storage path and input file name to complete export.

Different file formats can select types of export point with press on corresponding types. Point type includes Auxiliary Point, Survey Point, Control Point, Input Point, Calculate Point, Stake Point and Screen Point.

User-defined format setting: press [Format Manage] as shown in Figure 3.6-2, and press [New] to set up items as needed as shown in Figure 3.6-3. Setting up Field delimiter, Extension name, Angle format, whether to write File header, and select custom export format content. Select the content as needed, press [Add] to add the content to the Custom format description; press [Delete]

to delete the content of the custom format description one by one. Press [OK] to complete the custom export formatting as shown in Figure 3.6-4.

Select custom file format to do [Import], [Edit], And [Delete] operations on the file format.

2. Export Road Cross-section

Press [Export Road Cross-section] to enter into interface as shown in Figure 3.6-5. Select Data Files, File Format, Sort Type and Height Diff Type. Press [Export], choose file storage path and input file name to complete export. Export settings varies with File Format.




Figure 3.6-4




Figure 3.6-5

File Format includes Hintsoft Format (DH), TianZhen Format(H), KOLIDA CASS Cross-section File and Haiti. Hinsoft Format needs to set Sort Type and Height Diff Type. TianZhen Format only needs to set Sort Type while Haiti only needs to set Height Diff Type. KOLIDA CASS Cross-section needs to set nothing.

Height includes Relative to last point and Relative to road crown.

3.7 Scan

In SurvX, it's mainly to scan coordinate system QR code and configuration set. After scanning QR code, as shown in Figure 3.7-1, it can view content. Press [Apply] to apply the data in current project while press upper left return key to not apply parameters.




Figure 3.7-1




Figure 3.8-1

3.8 Cloud Settings

Press [Project] -> [Cloud Settings], and enable Cloud as shown in Figure 3.8-1. Input Cloud IP and Port, input user information and set up upload data settings. The server must be set up in accordance with PC terminal to upload survey data and download files from the server. Then the coordinate system file can be uploaded and downloaded quickly. In [Coordinate System], coordinate system parameters can be set to quickly uploaded Shared coordinate system parameters in real time.

3.9 Software Settings

Press [Project] -> [Software Settings] to enter into interface as shown in Figure 3.9-1. It includes Antenna Parameters, shortcuts Settings, Record Settings, Display Settings and other settings.

Shortcuts Settings: as shown in Figure 3.9-2, set up shortcut key for Points Library, set up shortcut keys for saving Topo Point, Control Point, Quick Point, Auto Point, Corner Point, Tilt Point and Tower Point, set up shortcut keys for Latest Point, Farthest Point, Last Point, Next Point in Stakeout. For P9A handheld, shortcut keys for collecting points default to Topo Point (1), Control Point (2), Quick Point (3), Auto Point (4), Corner Point (5), Tilt Point (6) and Tower point (7). It can customize the shortcut key as needed.




Figure 3.9-1




Figure 3.9-2




Figure 3.9-3

Record Settings: as shown in Figure 3.9-3, it can respectively set up storage condition and record options for Topo Point (as shown in Figure 3.9-4), Control Point, Quick Point, Auto Point, Corner Point, Stop & Go Point and Tilt Point, which also can use the default configuration.

System Settings: as shown in Figure 3.9-5, it can set up Distance Unit, Angle Format, Mileage Format, Language, Text encoding and whether Voice broadcast as needed.

Display Settings: as shown in Figure 3.9-6, it sets up the display status of coordinate points in Survey interface and set whether to display the map. It can set up Display Content, Display Type and whether to display map. If enabling map display, it can download offline maps to facilitate survey.






Figure 3.9-4

Figure 3.9-5

Figure 3.9-6

3.10 Software About

Software About as shown in Figure 3.10-1 includes three functions: Software activation, Feedback and Check Latest Version.




Figure 3.10-1




Figure 3.10-2




Figure 3.10-3




Figure 3.10-4




Figure 3.10-5

Software activation: press [Software activation] to enter interface as shown in Figure 3.10-2. There're mainly two ways to activate: Online activation and Offline activation. When with internet, it can use online activation while without it can use offline activation. As shown in Figure 3.10-3,

input registration code and press [Activate] to complete offline activation. Registration code transfer helps use our software on different devices.

Feedback: Thank you for using our software. Please leave your valuable comments. We will take your feedback seriously. As shown in Figure 3.10-4, you can write your feedback in the textbox and leave your contact information. It can also send us with appendix, which supports image and text. Press [Submit] and your feedback would automatically send to us.

Check Latest Version: press [Check Latest Version] to check if current software in latest version. If there is a new version, there would pop up Software update prompt as shown in Figure 3.10-5, and press [Details] to update software. If there is no new version, there would notice it's the latest version.

Chapter 4 Device

4.1 Communication

Press [Device]->[Communication] to enter into interface as shown in Figure 4.1-1. Set up Device Type, and press [Connect] to complete the device connection. When communication is not connected, the icon is grey. And the icon will turn blue after communication.




Figure 4.1-1




Figure 4.1-2

Device Type: RTK, M5, Kolida, Kolida(K96T), Internal GPS (only display this option when device has internal GPS) and Total Station.

The following is introduction of communication mode with connection to Kolida and Total Station. RTK Communication Mode: Bluetooth; Total Station Communication Mode: Bluetooth and Serial Port, with interface as shown in Figure 4.1-1.

(1) Bluetooth connection

Select [Bluetooth] and press [Search] as shown in Figure 4.1-2. If the Bluetooth of device need to connect is displayed in "Bluetooth Device List", you can press [Stop] to stop searching. Select the device Bluetooth needs to connect and press [Connect]. When there pops up matching dialog box, press [Pair] to connect. Bluetooth communication mode of Total Station is the same with that of RTK.

(2) WIFI connection (not support with KOLIDA receiver now)

With Device Type of RTK, select [WIFI] as Communication Mode and press [Search]. WIFI Device would be listed with its WIFI name (defaults to receiver SN). Select WIFI name to connect to the device WIFI and press [Connect] to complete connection as shown in Figure 4.1-4. [Fast connection] is to search the WIFI signal around and automatically connect to the one with largest signal intensity.

(3) Serial Port

With Device Type of Total Station select [Serial Port] as Communication Mode. Then connect handheld and device with data cable, set up Port and Baud, and press [Connect] to complete connection as shown in Figure 4.1-5.




Figure 4.1-4




Figure 4.1-5




Figure 4.1-6

(4) Demo

With Device Type of RTK, select [Demo]. As shown in Figure 4.1-6, set up Start Point coordinates and Direction (random or manually input) and press [Start] to enter into Demo mode. In Demo mode, it can check and try out various functions of the software.

4.2 Rover mode

Press [Device] ->[Rover] to enter into interface. As shown in Figure 4.2-1, Rover mode settings include Cut angle, whether to record raw data, Data link and advanced settings. The following is detailed introduction.




Figure 4.2-1




Figure 4.2-2

Cut angle: The angle between the connection line between satellite and receiver and the horizon. The receiver does not receive satellites that are below the elevation mask. Value range: 0-45° .

Record raw data: when it's enabled, it can input Point name and collect post-differential point in Point survey interface.

Data Link: enable/disable data link, RTK Network, Internal Radio, External Radio, Bluetooth Data Link.

1. None: no differential signal is transmitted.
2. RTK Network: transmit differential signal through RTK internal network. It needs to insert SIM card to transmit data.
3. Internal Radio: transmit differential signal through RTK internal radio. Base transmits differential signals through internal station, and rover receives differential signals from base through internal radio.
4. External Radio: transmit differential signal through large radio connected with receiver.
5. Bluetooth Data Link: transmit differential signal through handheld's network. It needs to insert SIM card to transmit data.

Select appropriate data link mode, and when set up successfully, rover can receive differential signals from the base. If internal radio mode is used, the frequency and protocol settings of rover and base must be consistent.

Advanced: as shown in Figure 4.2-2, it includes 5 satellite systems, namely GPS, GLONASS, BEIDOU, Galileo (only displays when receiver supports) and SBAS. It can select whether to receive signal from corresponding systems as needed.

4.2.1 Rover-RTK Network

Select Data Link as RTK Network to enter into interface as shown in Figure 4.2.1-1. It needs to set up Connect Options, WIFI Settings or APN Settings, CORS Settings and MountPoint Settings.

Connect Options needs to set up Connect Model, GGA upload intervals (defaults to 5 s, can be user-defined), whether to Automatically connect to network (when enable, receiver would automatically connect to the Internet once powered on), Network system (Auto, GSM and CDMA1x), Network mode (WIFI or GPRS. Selecting WIFI would appear WIFI Settings and selecting GPRS would appear APN Settings) and whether to use Network Relay. Connect Mode option details are as follows:

TCP: transmission control protocol. It is a connection-oriented, reliable, byte flow-based transmission communication protocol.

NTRIP: standard network transmission differential mode, commonly used in CORS networks.

Custom: user-defined.

ZHD: differential transmission mode of HI-TARGET network, which needs to set group number and subgroup number.

HUACE: differential transmission mode of CHC network.




Figure 4.2.1-1




Figure 4.2.1-2

WiFi Settings requires receiver with WiFi function. Press **⋮** to search WiFi, select WiFi hotspot and input password to connect WiFi.

CORS Settings needs to set IP, Port, User and Password. For User and Password, if you set up your own base, User and Password can be set at will; if you are using someone else's CORS account, you need to enter the password for that account. In addition, you can press **⋮** on the right to customize information about the CORS server.

MountPoint Settings needs to press [Get Access Point] and enable Automatically connect to network so that it can choose rover access point in the MountPoint list (generally access point defaults to base receiver number).

When everything is set up for rover, press [Apply] to complete rover receiver network data link setting.

4.2.2 Rover-Internal Radio

Select Data Link as [Internal Radio] to enter into interface as shown in Figure 4.2.2-1. It needs to set Channel, Frequency and Protocol. Channel 1-7 is fixed channels, whose frequency is unchangeable. Radio Protocol includes SOUTH and Trim Talk 450S(T).




Figure 4.2.2-1




Figure 4.2.3-1

4.2.3 Rover-External Radio

Select Data Link as [External Radio] to enter into interface as shown in Figure 4.2.3-1. It needs to set Baud Rate, which defaults to 38400.

4.2.4 Rover-Bluetooth Data Link




Figure 4.2.4-1

Select Data Link as [Bluetooth Data Link] to enter into interface as shown in Figure 4.2.4-1. It needs to set Connect Mode, CORS Settings and MountPoint Settings. The setup method is the

same as RTK Network, except that the network used comes from the mobile device, which requires the mobile device to be able to access the Internet.

4.3 Base mode

Press [Device] -> [Base] to enter into interface as shown in Figure 4.3-1, set up all parameters and press [Apply] to set receiver as base. If receiver does not open in base mode, its base parameters can be modified and receiver can be set to be base; if receiver opens in base mode, it can stop base and then set base parameters.

Base mode settings include Base ID, Start Up Mode, Diff Mode, Base Startup, Record raw data and Data Link. The following introduces various parameter settings.




Figure 4.3-1




Figure 4.3-2

Start Up Mode: Base mode settings includes 2 Start Up Modes: Use Current Coordinates and Input Base Coordinates.

- a) Use Current Coordinates: base uses WGS-84 coordinate of current point as base coordinates.
- b) Input Base Coordinates: user determines base coordinate. User-defined base coordinate cannot be too different from the exact WGS-84 coordinate of current point, otherwise the base station cannot work normally.

Press [Input Base Coordinates] as shown in Figure 4.3-2, base coordinate can be selected from points library, or acquired current GPS coordinate, or input manually. Press

[Antenna Parameters], select Antenna Measurement Type and input Antenna Measured Height to obtain antenna height.

Differential Mode: includes RTCM2, RTCM3, CMR, CMRPLUS, DGPS and RTCM32.

Data Link: set up current data link, including None, RTK Network, Internal Radio, External Radio and Dual.

1. None: no differential signal is transmitted.
2. RTK Network: transmit differential signal through RTK internal network. It needs to insert SIM card to transmit data.
3. Internal Radio: transmit differential signal through RTK internal radio. Base transmits differential signals through internal station, and rover receives differential signals from base through internal radio.
4. External Radio: transmit differential signal through large radio connected with receiver.

Select appropriate data link mode, and when set up successfully, rover can receive differential signals from the base. If internal radio mode is used, the frequency and protocol settings of rover and base must be consistent.

Advanced: as shown in Figure 4.3-3, set up Cut angle, PDOP limit, Delay Start and Satellite systems.

Cut-off angle: The angle between the connection line between satellite and receiver and the horizon. The receiver does not receive satellites that are below the elevation mask. Value range: 0-45° .

PDOP limit: Position Dilution of Precision. The smaller the PDOP value is, the better the satellites distribute. When it is less than 3, it is in the ideal state.

Satellite systems: it includes 6 satellite systems, namely GPS, GLONASS, BEIDOU, Galileo (only displays when receiver supports), SBAS and L-band. It can select whether to receive signal from corresponding systems as needed. L-band, the satellite communication band with frequency range from 0.39 to 1.55GHz, is often called 1.5GHz band.




Figure 4.3-3

4.3.1 Base-RTK Network

Select Data Link as RTK Network to enter into interface as shown in Figure 4.3.1-1. It needs to set up Connect Options, WIFI Settings or APN Settings and CORS Settings.

Connect Options needs to set up Connect Model, whether to Automatically connect to network (when enable, receiver would automatically connect to the Internet once powered on), Network mode (WIFI or GPRS) and Network system. Connect Mode option details are as follows:

NTRIP: standard network transmission differential mode, commonly used in CORS networks.

Custom: user-defined.

ZHD: differential transmission mode of HI-TARGET network, which needs to set group number and subgroup number.

HUACE: differential transmission mode of CHC network.




Figure 4.3.1-1




Figure 4.3.1-2

WIFI Settings requires receiver with WIFI function. Press **...** to search WIFI, select WIFI hotspot and input password (if needed) to connect WIFI.

CORS Settings needs to set IP, Port, Base access point (generally access point defaults to base receiver number) and Password. In addition, you can press **...** on the right to customize information about the CORS server.

4.3.2 Base-Internal Radio

Select Data Link as RTK Network to enter into interface as shown in Figure 4.3.2-1. It needs to set Channel, Frequency, Protocol and Power. Channel 1-7 is fixed channels, whose frequency is unchangeable; Channel 8 is user-defined channel, whose frequency can be set as needed. Radio Protocol includes SATEL, PCC-EOT(4FSK), PCC-EOT(GMSK) and Trim Talk 450S(T). The power level of base will affect the operating distance of radio: low power and low power consumption lead to close range of action; high power and high power consumption lead to long operating distance.




Figure 4.3.2-1




Figure 4.3.3-1




Figure 4.3.4-1

4.3.3 Base-External Radio

Select Data Link as [External Radio] to enter into interface as shown in Figure 4.3.3-1. It needs to set Baud Rate, which defaults to 38400.

4.4 Static mode

Press [Device] -> [Static] to enter into interface as shown in Figure 4.4-1. Static mode settings include Options Settings and Antenna Parameters. The following introduces all parameter settings in detail.




Figure 4.4-1




Figure 4.4-2

- Options Settings

Point name: point name of static data.

PDOP limit: The geometric strength factor of the satellite distribution. The smaller the PDOP value is, the better the satellite distribution is. PDOP value less than 3 is the ideal state.

Cut angle: The angle between the connection line between satellite and receiver and the horizon. The receiver does not receive satellites that are below the elevation mask. Value range: 0-45°.


Collection interval: 1HZ represents that the acquisition of a data per second, 5HZ represents that the acquisition of five data per second, 5s represents that two seconds to collect a data, and so on.

Auto record static data: If it's enabled, receiver will start recording automatically when it is powered on and receiving satellites signal; If it's disabled, you need to start recording static data manually after receiver is powered on.

- Antenna Parameters

Antenna Measured Height: height of the measured point above ground.

Antenna Height: vertical height(h) from the phase center of the antenna to ground.



The known values which receiver provided as follows:

b: The height from the bottom of the device to the phase center p.c.;

c: The height from the bottom of the device to the rubber ring;

R: The radius of the device rubber ring.

If the measured height is the vertical height (a) from the bottom of device to the ground, its measurement mode is Upright height from device bottom. The antenna height: $h=a+b$.

If the measured height is the height from the phase center to the ground, its measurement mode is Height from Phase Center. The antenna height: $h=h$.

If the measured height is the slant height (s) from the rubber ring to the ground, its measurement mode is Slant height from measuring line. Antenna height: $h = \text{sqrt}(s^2 - R^2) - c + b$ (sqrt means open square).

Altimetry piece is an accessory fixed to the bottom of device. If the measured height is the slant height(S) from the altimetry piece to the ground, and with the known radius of altimetry piece R_c , its measurement mode is Slant height from Altimetry piece. Antenna height: $h = \text{sqrt}(S^2 - R_c^2) + b$.

Antenna height is usually defined as the vertical distance from the phase center of antenna to measuring point. Since it cannot be directly measured, it is usually calculated by other measurement methods. The antenna height can be obtained by inputting measured height and selecting measurement mode.

After setting all parameters in static mode setting, press [apply] to set receiver to static mode.

- advanced

Satellite systems: it includes 5 satellite systems, namely GPS, GLONASS, BEIDOU, Galileo (only displays when receiver supports) and SBAS. It can select whether to receive signal from corresponding systems as needed.

SBAS: Wide-area differential augmentation system (satellite-based augmentation system). The navigation satellites are detected by a large number of widely distributed differential stations and the acquired raw data is sent to console. And then console calculate to acquire various satellite positioning correction information and sent to the GEO satellites through the upload station. Finally, GEO satellites will send the correction information to users, which facilitates to improve the positioning accuracy.

After setting all parameters in static mode setting, press [apply] as shown in Figure 4.2-2 to set receiver to static mode.

4.5 Information

Press [Device] -> [Information] to enter into interface as shown in Figure 4.7-1. When handheld connects to receiver, it can read receiver information, including Device information, Network info, Radio info and Other information.

| Device Information | |
|-----------------------|-----------------|
| Serial | 861097030703262 |
| Model | Stonex S3II |
| Hardware Version | S3II-V1.30 |
| BIOS Version | 1.05 |
| Firmware Version | 0.22.170721 |
| GNSS Firmware Version | OM7MR0400RN0000 |
| GNSS Serial | BMGX18020299Y |
| OS Version | 1.09 |
| MCU Version | 1.07 |

Navigation tabs: Device information (selected), Network info, Radio info, Other

Figure 4.7-1

4.6 Calibrate Sensor

Press [Device] -> [Calibrate Sensor] to enter into operation main interface. Main interface includes E-Bubble, Magnetic calibration. The following introduces the operation in detail.




Figure 4.9-1




Figure 4.9-2

1. Open Pole Tilt Correction

Press [Survey] -> [Point survey], click e-bubble button to activate the tilt sensor shown in Figure 4.9-3, then you will see e-bubble in the screen Figure 4.9-4.




Figure 4.9-3




Figure 4.9-4

2. E-Bubble

(1) Press [Calibrate Sensor] to enter into E-Bubble calibration interface as shown in Figure 4.9-1. And select E-bubble.

(2) Center the bubble on the retractable pole and press [Start]. E-bubble and bubble on the retractable pole are in center at the same time and E-Bubble is shown in green as shown in Figure 4.9-2.

3. Magnetic step calibration

Select Magnetic as shown in Figure 4.9-5. Then click start button to do the magnetic calibration. Next you need to rotate and flip the receiver to different direction until the progress bar is finished shown as Figure 4.9-6.

Afte all calibration are finished, the software will jump to the main interface automatically, then you can start to use the tilt survey fuction.



Figure 4.9-5





Figure 4.9-6

4.7 Device Register

After connection between handheld and receiver, it can view device SN and registration date as shown in Figure 4.11-1. When it needs to register the RTK, in one way it can input activation code manually, and in the other way it can press  to scan QR code to acquire activation code. After inputting activation code, press [Registration] to complete registration. For activation code of device, you can contact GeoElectron or dealer.

Chapter 5 Survey

5.1 Point Survey

Press [Survey] -> [Point Survey] to enter into interface as shown in Figure 5.1-1.








Figure 5.1-1


- The icons in upper toolbar describe as follows:

 Close/exit Point Survey interface.

 Receiver operation mode, pressing to jump to Base/Rover/Static setting interface.

 Receiver signal.

 Receiver positioning information, pressing to jump to satellite positioning information interface.

 Receiver battery power.

Solution status: includes single, float, differential and fixed.

[Age9]: current differential delay is 9.

[Single, 0]: current solution is single, and differential delay is 0.

[Static, 0]: "Static" shows sensor status when the pole tilt survey is enabled, and "0" means that the tilt angle is 0.

[H]: HRMS, the value represents the horizontal accuracy of current point.


[V]: VRMS, the value represents the vertical accuracy of current point.

[27/30]: current number of satellites which used to solution, and the total tracked satellites number.

- The icons in left toolbar describe as follows:

 Perimeter and area


 Switch the map

 Jump map center


 Enable E-Bubble

 Static Record

 Fold/Open toolbar

 CAD-polyline

 CAD-rect center

 CAD-circle 2p


 CAD-arc


 CAD-Default


 Coordinates Converter

 Full Map

 Disable Tilt Survey

 Enable Tilt Survey


 Auto jump map center

 CAD -square center

 CAD -rect


 CAD-polygon

 CAD-square

 CAD-circle 3p

 CAD-point

- The icons in right toolbar describe as follows:

 Coordinate point library: as shown in Figure 5.1-2, points collected by SurvX are stored in coordinate point library.

Press [New] to create a new point.

Select any coordinate point and press [Edit] to edit the point information.

Press [Details] to view detailed information of the point.

Press [Delete] to delete the point.

Press [Import] to import coordinate file.

Press [Options] to enable/disable point types to filter points in the coordinate point library by point type.




Figure 5.1-2




Figure 5.1-3

Display information (with interface as shown in Figure 5.1-3):

TOPO POINT: settings for display limit of collected points on the basis of set point type that defaults to topo points.

INFORMATION BAR: it can select the displayed information in the status bar at interface bottom. Select an item in the Options list, then press to move this item to the Display item list. In the same way, select an item on the Display item list, and press to move this item to the Options list. If press [Default], the default items will be added to the Display item list, including point name, H, N, E, Antenna height and Base distance.

TOOLBARS: settings what function keys to display in left toolbar in Point Survey interface.

: Static Record. As shown in Figure 5.1-4, set Point name (point name of point in static record), Cut angle, Collection Interval, Observation Time and Antenna Parameters, press [Start] and as shown in Figure 5.1-5 it starts static record. When static record is finished, it would save a static record file in receiver. The static collection data here is the same as that collected

under static mode except for it can also collect topo points under rover mode as shown in Figure 5.1-6.




Figure 5.1-4




Figure 5.1-5




Figure 5.1-6

Collect point coordinates: this icon changes along with open/close status of tilt survey.

Open tilt survey and then this icon would show E-Bubble status and also collect points by pressing on it.

- The icons in right toolbar describe as follows:

Point name: point name of collected point.

N, E, H: horizontal coordinates (projection point) of the current point.

Antenna height: antenna height set in survey.

Base distance: The distance from current rover to the base.

Code: code for last point.

- Press to set the point type (Topo Point, Control Point, Quick Point, Auto Point, Corner Point and Tilt Point). The following introduces collecting process of all point types.

Topo point: The “average GPS count” in record options refers to the number of points which could be consecutive recorded. Please refer to the Figure 5.1-7, it means that it could collect one point every time and this point should meet record limit. When you press to record the topo point, if the measured point does not meet record limit, there will be a prompt message. If the

measured point meets record limit, the measured point info (HRMS, VRMS, delay, PDOP, date and time) will be displayed in the screen. Then press [OK] to save the topo point.




Figure 5.1-7




Figure 5.1-8




Figure 5.1-9

[Photo and Sketch] It can make information note on collected points, such as documents, pictures and graphs as shown in Figure 5.1-9.

: Undo and return to previous step.

: Add text. Font size and text color can be set.

: Add point information. Font size and color and point information to be added (name, code, north, east, height) can be set.

: Add arrow. Arrow color and style can be set.

: Add drawing. Similar to the pencil function in Windows Paint, color and thickness can be set.

: Add photo. Directly invoke camera to take a picture to add into information.

: Move. It can move any added information.

: Rotate. It can rotate any added information.

: Zoom. It can zoom in or out any added information.

: Clear. It can clear away all information.

Control point: to collect control points will enter into interface as show in Figure 5.1-10. Press [Control Point] and wait for 15s delay for fixed solution, then it starts to collect data. It records one point every 2s, continuously records 10 points and collects 2 sets of 10 points (the above data is taken for example according to the control points record settings). When collection is finished, press [OK] and it will pop up prompt [Control points report generated, name as XXX, would you like to view it now?] as shown in Figure 5.1-11. Press [OK] to check control point survey report as shown in Figure 5.1-12.




Figure 5.1-10




Figure 5.1-11

GPS control point measurement report

Basic Information

| | |
|------------------|----------------------------|
| Project ame | (20181011 - 20181011_1.PD) |
| Operator | |
| Report Time | 2018-10-12 10:05:29 |
| Antenna Height | 0.0743 |
| Observation Time | 19 |

Coordinate systems parameters

| | | |
|------------------------|----------------|---------------|
| Coordinate system name | default | |
| Ellipsoid Parameter | Ellipsoid Name | CGCS2000 |
| | Semimajor axis | 6378137.0 |
| | 1/f | 298.257222101 |
| Projections Mode | Gauss Kruger | |

Figure 5.1-12

Quick point: When you collect quick point, if the measured point meets record limit, then it will finish collection after prompt voice, and there will not pop up storage interface.

Auto point: To collect auto point, choose [Auto Point] and press to set record parameters and then press collect key to start collection as shown in Figure 5.1-13. If you want to pause the recording progress, please press [pause], and press [start] to start recording, press [Stop] to end the auto points recording.




Figure 5.1-13




Figure 5.1-14




Figure 5.1-15

Corner point: Corner point collecting interface as shown in Figure 5.1-14. Every time it records corner point, it should record at least 15 points, and distance between two points should be greater than 1/10 of pole height. Then it can calculate the unknown point coordinates by these corner points. Press [Antenna Parameters] to set Antenna Measured Height and Antenna Measurement Type, press [OK] to start collection, and after collecting 15 points there will pop up interface as shown in Figure 5.1-15 to complete collection.

Tilt point: press to enter into collection interface as shown in Figure 5.1-16. If RTK has tilt survey function, it can calculate the unknown point by collecting two tilt points; if RTK only has E-Bubble function, it can calculate the unknown point by collecting three points. Set up Antenna Measured Height, place mounting pole in the unknown point, tilt in one direction and it automatically collect the first tilt point (interface of successful collection of first point as shown in Figure 5.1-17). Then tilt in another two directions and it automatically collect the second and the third tilt point. Its collection interface is shown in Figure 5.1-18. Three circles intersect with each other and press [Save] to calculate the unknown point.




Figure5.1-16

Figure5.1-17

Figure5.1-18

5.2 Detail Survey

Press [Survey] -> [Detail Survey] to enter into interface as shown in Figure 5.2-1. Its upper toolbar information is same as that of Point Survey. Detail Point is a simplified point survey mode, which is suitable for rapid and continuous coordinate survey.




Figure 5.2-1

Figure 5.2-2

Taking topo point collection as example, press [Settings] as shown in Figure 5.2-2, select whether to enable Tilt Survey, set recording limit (can use default settings) and press [OK] to return to interface as shown in Figure 5.2-1. Press [Antenna Parameters] to set Antenna Measured

Height and Antenna Measurement Type, press [OK] to return to collection interface. If it needs to use Code library, press to edit code. Press [Start] to complete point collection.

5.3 CAD

CAD is mainly used to import and edit the existing CAD graphics, and stakeout lines in the existing CAD graphics.

Press [Survey] -> [CAD] to enter into interface as shown in Figure 5.3-1. The following introduces this interface in detail. Press [3D] to enter 3D view as shown in Figure 5.3-2.




Figure 5.3-1

Figure 5.3-2

Figure 5.3-3

[Data] It can manage layer and import/export *.DXF files. To export *.DXF file it needs to set whether to export Coordinate point Library, Point Name, Code and Elevation.

Press [Data]->[layer] to enter interface as shown in Figure 5.3-3. Press [NEW LAYER] to enter interface as shown in Figure 5.3-4, input Layer Name, set layer color, select whether to set up as a work layer, whether visible and whether lock, and press [OK] to complete creating a new layer. Press layer and as shown in Figure 5.3-5, it can perform Rename, Delete, Batch delete and Delete all. Long press layer and it can perform batch delete as shown in Figure 5.3-6. represents current work layer. represents layer is visible. represents layer is invisible. represents layer is locked and layer locked cannot be deleted. represents layer is unlocked.




Figure5.3-4




Figure5.3-5























Figure 5.3-6

[Drawing] It can draw layer according to points.

[Survey] It can calculate intersection point, distance offset and perform other functions.

[Tools] It can calculate angle and area.

- Layer (creating new layer)
- Export *. dxf file
- Import *.dxf file
- Arc
- Polyline
- Square
- Polygon
- Rect
- Square center
- Circle 2p
- Rect center
- Int 2 Dist
- Circle 3p
- Int 4 Point
- Dist offset
- Dist offset

| | |
|---|---|
|  Divide |  Measure |
|  Invert |  Delete |
|  Angle |  Area |
|  3D Default view |  3D Top |
|  3D Front |  3D Back |
|  3D Left |  3D Right |
|  3D SW |  3D SE |
|  3D NE |  3D NW |
|  whether display Name |  whether display Grid |
|  Elevation | |

CAD delete data and stakeout:

Press point or figure needs to delete on the screen, select the target and target turns to be in blue as shown in Figure 5.3-7, and press [Delete] to delete target as needed. Press [Stakeout] to enter interface as shown in Figure 5.3-8, select [Use selected polyline] or [Use selected segment], set whether to enable [Setting out by pile by coordinate], press [OK] to enter stakeout interface and perform stakeout. Press [List] and it can view selected Object information as shown in Figure 5.3-9, and it can select point in Object Info to stakeout.




Figure5.3-7




Figure5.3-8




Figure 5.3-9

5.4 Point Stakeout

Point stakeout is the process of inputting target coordinate in software and stakeout in field.

Press [Survey] -> [Point Stakeout] -> [Point Library], select the point and press [OK] to enter interface as shown in Figure 5.4-1.




Figure 5.4-1



Figure 5.4-2

Arrows in left bar describe as follows:

To North/South: distance that receiver needs to move North/South from current position to stakeout point. To North arrow shows up and To South arrow shows down.

To West/East: distance that receiver needs to move West/East from current position to stakeout point. To West arrow shows left and To East arrow shows right.

Fill/Cut: dig in stakeout point position. If the value is positive, perform excavation; if not, perform fill. If current height is higher than stakeout point arrow shows down. If current height is higher than stakeout point arrow shows up.

: open/close stakeout voice prompt.

: hide or show left arrow bar.

: switch compass mode or distance mode. Distance mode is as shown in Figure 5.4-1 and compass mode is as shown in Figure 5.4-2. There are two states for compass mode. State 1 is as shown in Figure 5.4-2. Red flag represents target point, blue arrow represents moving direction from current receiver position to stakeout point, and red words below represents distance to target point. State 2 is as shown in Figure 5.4-3. In gray circle the red flag represents stakeout target, and blue circle represents receiver position. When stakeout distance doubles Prompt Range, it would change state 1 into state 2; when stakeout distance meets Collection scope, state 2 blue circle would turn into green.




Figure 5.4-3






Figure 5.4-4


The icons in side toolbar describe as follows:

 : Coordinate point library. Points collected by SurvX are stored in coordinate point library.

 : Stakeout last coordinate.

 : Stakeout next coordinate.


 : The closest point, the point closest to stakeout point.

 : Point stakeout settings: as shown in Figure 5.4-4, it can set stakeout settings, including Prompt Range, Collection scope and Display Information (No Display, Point Name, Code); settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey. Press [DEFAULT] and it can restore the changed settings.

Automatic scaling: when automatic scaling is enabled, point stakeout will zoom screen according to distance between stakeout point and current point to full display the points.

Prompt Range: taking stakeout point as center of a circle and drawing three concentric circles with radii are multiples of 1, 2 and 3 times of the prompt range, area covered by these three concentric circles is prompt range.

Collection scope: prompt range of distance between stakeout point and current point, which defaults to 0.2m. When the collected point is in this range, it will not be prompted; if not, it will be prompted.

 : collect topo point.

Defaulted items in bottom status bar describe as follows:

Target: point name of current stakeout point.

Distance: distance between receiver and stakeout point.

To North: distance that receiver needs to move north from current position to stakeout point.

To East: distance that receiver needs to move east from current position to stakeout point.

Fill: dig in stakeout point position. If the value is positive, perform excavation; if not, perform fill.

Antenna height: antenna height in survey.




Figure 5.4-5




Figure 5.4-6

Point stakeout steps:

1. Select a point to stakeout in the points library, then press [OK] to enter stakeout interface as shown in Figure 5.4-5. Red flag is target stake point. Circle is current position of receiver. Arrow is direction indicator, indicating the direction of current receiver. When the arrow direction is same with the direction to the target point, please move in this direction, then you can reach the target point.

2. According to bottom status bar, move from the current point to the coordinate of stakeout point, and excavate or fill the soil according to the height difference of the elevation.

3. When current point is within prompt range, there will be three concentric circles as shown in Figure 5.4-6, which indicate it enters precise stakeout.

4. The adjacent stakeout points in the points library can be switched automatically by \uparrow and \downarrow keys.

5. After you reach the stakeout point, please stake it.

5.5 Line Stakeout

Line stakeout is the stakeout of designed line, including line mileage, left and right offset and elevation control within line.

Press [Survey] -> [Line Stakeout] -> [Lines Library], select the line and press [OK] to enter interface as shown in Figure 5.5-1.




Figure 5.5-1




Figure 5.5-2

The icons in right toolbar describe as follows:

: Lines library. As shown in Figure 5.5-2, Lines library includes six operations, namely Add, Edit, Delete, OK, Import and Export.

Press [Add] to enter interface as shown in Figure 5.5-3, input line name and start mileage, select input type, input parameters, and press [OK] to complete line parameter settings of new line. There are two ways to input line parameters: one is to set start point and end point of line, and it automatically calculates azimuth and length (start mileage defaults to 0); the other one is to set start point, azimuth and length.

Select any line in Lines library and press [Edit] to edit the line information, and press [OK] to save the change.

Select any line in Lines library and press [Delete] to delete the selected line.




Figure 5.5-3




Figure 5.5-4

Press [import] to enter interface as shown in Figure 5.5-4. If you select Data Type as [Lines File] and set File Format (defaults to Line Library File, and it can be defined by press on [Format Manage]), then you can import the file with*. SL suffix. If you select Data Type as [Coordinates File] and set File Format (defaults to Local coordinates format, and it can be defined by press on [Format Manage]), then you can import the file with *.dat suffix. The imported line file can be a line file in another project or a pre-edited line file, avoiding duplicate entries.

Press [Export], select export path and input file name to complete export. The line file (*.SL) in the project can be exported to specified path and used for other data processing or project import.

↶ : stakeout last line.

↷ : stakeout next line.




Figure 5.5-5




Figure 5.5-6

: Add stake. As shown in Figure 5.5-5, it can add stake in line stakeout. There are two modes to add stake. First mode, calculate coordinates by mileage and offset distance, in which it needs to input mileage, offset distance. Second mode, calculate offset and distance by coordinates, in which it needs to input northing, easting and elevation, or search coordinates from library, or get current GPS coordinates. After setting up parameters, please press [OK], and there will pop up the prompt to display the calculate result. Then it can press [Stakeout] to stake.

: Display information. Set up display information, including Prompt Range and Display all line, as shown in Figure 5.5-7. Press [DEFAULT] and it can restore line stakeout settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.




Figure 5.5-7




Figure 5.5-8




Figure 5.5-9

Prompt range: Taking the line as center and prompt range as spacing on both sides, it generates six parallel lines. The area within these six parallel lines is prompt range.

Automatic scaling: when automatic scaling is enabled, line stakeout will be displayed in full screen automatically.

: collect TOPO point.

Defaulted items in bottom status bar describe as follows:

Target: The name of the stakeout line.

H: The height of current point.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.

Mileage Diff to Start: Draw a vertical line from current point to stakeout line, and Mileage Diff to Start is the distance from foot point to start point.




Mileage Diff to End: Draw a vertical line from current point to stakeout line, and Mileage Diff to End is the distance from foot point to end point.

Target peg: The name of the current stakeout peg.

Line stakeout steps:

1. According to the engineering design, please edit the stakeout line in the line library or import line file in advance.
2. Select the Stakeout line and press [OK] to enter line stakeout interface. Start point shows mileage 0.000 and end point shows actual mileage. Red flag represents vertical distance from current point to line. Arrow indicates the direction of RTK. Please refer to Figure 5.5-8.
3. Moving direction: Move along the vertical line from current point to the stakeout line, you can return to the stakeout line. Or according to the prompt direction in the bottom status


bar, you can also find the correct direction to reach the stakeout line (You can change the items in the bottom of the status bar).



4. Please stakeout according to the prompt in the bottom status bar.
5. When the line offsets on both sides are within the prompt range, the parallel lines are generated on both sides of the stakeout line according to the setting of Prompt Range. It indicates that you are in precise stakeout.
6. If you need to add stake to line during stakeout process, press  to set stake mode and position, then press [OK] to acquire calculation result. Press [Stakeout] to enter line stakeout interface as shown in Figure 5-21. Then you can stake out according to the prompts in the bottom status bar. When the distance between stakeout point and current point is less than 3 meters, it will take stake point as center and generate prompt circles to get into precise stakeout.
7. The adjacent stakeout lines in Lines library can be switched automatically by  and  keys.

5.6 Stake road

Stake road is the specific program for stakeout of line and channel median line and slope construction in line engineering and hydraulic engineering.

Press [Survey] -> [Stake road], select the stakeout road and press [OK] to enter interface as shown in Figure 5.6-1.

 : Road Library. It includes [New], [Edit], [Delete], [Import] and [OK] five operations. Press [New] and input Road Name, select Road type and input corresponding parameters to create a new stakeout road. Select any road in Road Library, press [Edit] and it can edit name and parameters of the road. Press [Delete] and it can delete the road from Road Library. Press [Import], change path and select stakeout road file (*.RE, *.LE, *.RP, *.IP, *.rec, *.dat, *.csv, *.txt) and it can import stakeout road file as shown in Figure 5.6-2. The imported road file can be a stakeout road file in another project, to avoid duplicate entries.

 : central line of road. It can switch to slope stakeout  by press. Slope stakeout: it is to stakeout the designed road on the drawing to the corresponding ground in accordance with the

design requirements in order to instruct surveyor to mark the excavation line and filling line for construction.

: Display information. It can set stakeout road configuration, including Prompt Range, Display key point, Assistant line, Road thickness and Limit mileage range as shown in Figure 5.6-3. Press [DEFAULT] and it can restore changed items. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.




Figure 5.6-1




Figure 5.6-2




Figure 5.6-3

: collect TOPO points.

The items in the bottom status bar description:

Target: The name of the stakeout road.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.




Figure 5.6-4




Figure 5.6-5

Road stakeout steps:

1. According to the engineering design, please edit the stakeout road in Road Library.
2. Select the stakeout road and press [OK] to enter road stakeout interface. And stakeout according to the prompt in the bottom status bar as shown in Figure 5.6-4. Draw vertical line of stakeout line over current point. Red flag indicates foot point, circle indicates current point, and arrow indicates direction of RTK.
3. Press to enter slope stakeout interface as shown in Figure 5.6-5. It will automatically display slope graph in the range of current mileage based on the currently calculated mileage. In screen it displays current point's position in slope in real time, and bottom status bar displays specific data of Distance to Slope, Distance to Top/Bottom, Height and Cut and Fill. In graph the middle red of cross section shows current mileage, and the blue number shows the offset at the intersection of related plates

5.7 Stake road by point

Stake road by point is the specific program for continuous stakeout of specific stakes with fixed stake distance like 20/50/100 or with specific stake number as engineering required.

Press [Survey] -> [Stake road by point], select the stakeout road to stakeout and to enter interface as shown in Figure 5.7-1.




Figure 5.7-1







Figure 5.7-2

 : Road Library. It includes [New], [Edit], [Delete], [Import] and [OK] five operations. Press [New] and input Road Name, select Road type and input corresponding parameters to create a new stakeout road. Select any road in Road Library, press [Edit] and it can edit name and parameters of the road. Press [Delete] and it can delete the road from Road Library. Press [Import], change path and select stakeout road file (*.RE, *.LE, *.RP, *.IP, *.rec, *.dat, *.csv, *.txt) and it can import stakeout road file as shown in Figure 5.7-2. The imported road file can be a stakeout road file in another project, to avoid duplicate entries.

 : Add stake. It can add stake in road stakeout. There are two modes to add stake: one is to calculate coordinates by chainage and offset distance, and the other one is to calculate offset and distance by coordinates.

 : Display information. Set up display information, including Prompt Range and Display all line, as shown in Figure 5.7-3. Press [DEFAULT] and it can restore line stakeout settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

 : collect TOPO point.

Defaulted items in bottom status bar describe as follows:

Target: name of the stakeout road.

To Less: distance from current point to target peg. “To Less” means that if you want to reach the target peg, the distance to the direction of the small mileage.

Distance: distance between receiver and stakeout point.

Fill: dig in stakeout point position. If the value is positive, perform excavation; if not, perform fill.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.




Figure 5.7-3




Figure 5.7-4





Figure 5.7-5

Road stakeout steps:

1. According to the engineering design, please edit the stakeout road in Road Library.
2. Select the stakeout road and press [OK] to enter road stakeout interface as shown in Figure 5.7-4. Mileage can be set as needed, that is, when entering stakeout interface, the position of stakeout point. Set stakeout interval, and then perform stake road by points. Press [OK] to enter road stakeout interface as shown in Figure 5.7.5. And according to arrow direction and the prompt of mileage and offset in the bottom status bar, stakeout roads in Road Library at stakeout interval by points. The adjacent stakeout points in the points library can be switched automatically by ↑ and ↓ keys. Press  , input mileage

and it will automatically calculate coordinate of added stake, then press [OK] to return to stakeout interface for stakeout.

5.8 Stake road by cross section

Stake road by cross section is the specific program for measurement of surface relief vertical to road middle line on middle stake after design of line so as to meet early requirement of line engineer or hydraulic engineering. Cross section drawing is the basis for design of subgrade cross section and determining the excavation and filling of roadbed in construction. SurvX would export specific cross section file format used in related design software.

Press [Survey] -> [Stake road by cross section], select the stakeout road and enter interface as shown in Figure 5.8-1.




Figure 5.8-1






Figure 5.8-2

: Road Library. It includes [New], [Edit], [Delete], [Import] and [OK] five operations. Press [New] and input Road Name, select Road type and input corresponding parameters to create a new stakeout road. Select any road in Road Library, press [Edit] and it can edit name and parameters of the road. Press [Delete] and it can delete the road from Road Library. Press [Import], change path and select stakeout road file (*.RE, *.LE, *.RP, *.IP, *.rec, *.dat, *.csv, *.txt) and it can import stakeout road file as shown in Figure 5.7-2. The imported road file can be a stakeout road file in another project, to avoid duplicate entries.

 : Add stake. It can add stake in road stakeout. There are two modes to add stake: one is to calculate coordinates by chainage and offset distance, and the other one is to calculate offset and distance by coordinates.

 : Display information. Set up display information, including Prompt Range and Display all line, as shown in Figure 5.8-3. Press [DEFAULT] and it can restore line stakeout settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

 : collect TOPO point.

Defaulted items in bottom status bar describe as follows:

Target: The name of the stakeout line.

H: The height of current point.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.

Horizontal distance: Draw a vertical line from current point to cross section, and Horizontal distance is the distance from foot point to intersection of cross section and road.

Vertical distance: Draw a vertical line from current point to cross section, and Vertical distance is the distance from foot point to current point. "To more" means that if you want to reach the target peg, the distance to the direction of the big mileage. "To Less" means that if you want to reach the target peg, the distance to the direction of the small mileage.




Figure 5.8-3




Figure 5.8-4




Figure 5.8-5

Stake road by cross section steps:

Select target road and press [OK] to enter interface as shown in Figure 5.8-4. Set whether auto select mileage, Calculation mode, Interval and Normal (distance between middle line of road and side point of cross section). Press [OK] to enter stakeout interface as shown in Figure 5.8-5. When vertical distance of road is less than 3 meters, parallel lines are generated on both sides of the cross section to enter precise positioning. Move current point according to the arrow direction and vertical and horizontal distance prompt in bottom status bar. When current point is on cross section, perform data collection and stakeout according to engineer requirements. The adjacent cross section can be switched automatically by \uparrow and \downarrow keys. Press P , input mileage and it will automatically calculate coordinate of added stake, then press [OK] to return to stakeout interface for stakeout. When cross section is located in the position of pile mileage, it can be measured. Collected data can be exported through [Project]-> [File Export] to export in Hintsoft Format(DH), Haiti, TianZhen Format(H), SOUTH CASS Cross-section File Format.

5.9 Stake road by bridge section

Stake road by bridge section is the specific program for line stakeout of orthogonal culverts, oblique culverts and culvert median line. Oblique culvert describes culvert median line and line form a fixed angle.

Press [Survey] -> [Stake road by bridge section], select the stakeout road and add a bridge section as shown in Figure 5.9-1. (Notes: please select bridge-crossing road in Bridge management library, and create a new road according to road design if none.)




Figure 5.9-1




Figure 5.9-2

: Bridge management library. As shown in Figure 5.9-2, it includes Add, Edit, Delete, Import, Export and OK operation. Press [Add], as shown in Figure 5.9-3, set coordinates A and B, it will automatically calculate Intersecting Mileage and intersecting Angle and other parameters. And press [OK] to create a new bridge section. Select any bridge section and press [Edit] and it can edit every parameter. Press [Delete] and it can delete the selected bridge section. Press [Import]/[Export] and it can import/export bridge file in *.XDM format.

: Display information. Set up display information, including Prompt Range, Automatic scaling and Limit mileage range, as shown in Figure 5.9-4. Press [DEFAULT] and it can restore changed settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

: collect TOPO point.

Defaulted items in bottom status bar describe as follows:

Target: The name of the stakeout line.

H: The height of current point.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.

Horizontal distance: Draw a vertical line from current point to cross section, and Horizontal distance is the distance from foot point to intersection of cross section and road.

Vertical distance: Draw a vertical line from current point to cross section, and Vertical distance is the distance from foot point to current point. "To more" means that if you want to reach the target peg, the distance to the direction of the big mileage. "To Less" means that if you want to reach the target peg, the distance to the direction of the small mileage.




Figure 5.9-3




Figure 5.9-4




Figure 5.9-5

Stake road by bridge section is to create a new oblique section and then collect oblique section data. Oblique section is fixed angle between cross section and road.

Stake road by bridge section steps:

Press [Survey] -> [Stake road by bridge section] to enter interface as shown in Figure 5.9-2. Press [Add] to create a new oblique section as shown in Figure 5.9-3. Set coordinates A and B, and their connection line should intersect with road; or set Intersecting Mileage (directly input mileage values or press to acquire current point), Intersecting Angle and Length. Press [OK] to return to Bridge management library, select bridge section and press [OK] to enter stakeout interface as shown in Figure 5.9-5. Taking data in Figure 5.9-5 for example, mileage between current oblique

section and road is 2.62 meters (according to intersecting mileage settings). Move current point and when vertical distance of road is less than 3 meters, parallel lines are generated on both sides of the oblique section to enter precise positioning. Measure and stakeout oblique section according to the arrow direction and vertical and horizontal distance prompt in bottom status bar. When the distance between stakeout point and current point is less than 3 meters, it will take stake point as center and generate prompt circles to get into precise stakeout. When the distance between cross section and current point is less than 3 meters, it will take cross section as center and generate prompt circles to get into precise stakeout.

5.10 Conical Slope Stakeout

Conical slope stakeout is the specific program for stakeout of conical slope of abutment in the combining site of the road and bridge in road engineering.

Press [Survey] -> [Conical Slope Stakeout], select the stakeout road and add a conical slope as shown in Figure 5.10-1.




Figure 5.10-1




Figure 5.10-2




Figure 5.10-3

: Conical slope library. As shown in Figure 5.10-2, it includes Add, Edit, Delete and OK operation. Press [Add], as shown in Figure 5.10-3, set Mileage, Road width, Crossing angle, Slope and Slope bottom height. If it needs to use Road center coordinate, enable the option and input center point coordinate. And then after Conical Slope settings, press [OK] to create conical slope.

Select any conical slope and press [Edit] and it can edit all parameters of conical slope. Press [Delete] and it can delete the conical slope from conical slope library.

: Display information. Set up display information, including Prompt Range, Display key point and Display calculate Point, as shown in Figure 5.10-4. Press [DEFAULT] and it can restore changed settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

: collect topo point.

Defaulted items in bottom status bar describe as follows:

Target: point name of current stakeout point.

Fill: dig in stakeout point position. When the current elevation is greater than that of the stakeout point, perform excavation.

To North: distance that receiver needs to move north from current position to stakeout point.

To East: distance that receiver needs to move east from current position to stakeout point.

To Less: distance from current point to target peg. “To Less” means that if you want to reach the target peg, the distance to the direction of the small mileage.

To Right: distance from the current point to the left relative to the midline of the line.




Figure 5.10-4




Figure 5.10-5

Generally, a bridge has two bridge abutments, 0# and 1#. Usually see abutment with small number as 0#, and abutment on the other side as 1#. Conical slope is a construction between abutment and embankment, which is for bridge protection. If there is barricade behind abutment, then conical slope is not necessary.

Conical Slope Stakeout steps:

Press [Survey] -> [Conical Slope Stakeout] to enter interface as shown in Figure 5.10-2. Press [Add] to create a new oblique section as shown in Figure 5.10-3. Then Press [OK] to return to Bridge management library, select bridge section and press [OK] to enter stakeout interface as shown in Figure 5.10-5. Taking data in Figure 5.10-5 for example, mileage between current oblique section and road is 2.62 meters (according to intersecting mileage settings). Move current point and when vertical distance of road is less than 3 meters, parallel lines are generated on both sides of the oblique section to enter precise positioning. Measure and stakeout oblique section according to the arrow direction and vertical and horizontal distance prompt in bottom status bar. When the distance between stakeout point and current point is less than 3 meters, it will take stake point as center and generate prompt circles to get into precise stakeout. When the distance between cross section and current point is less than 3 meters, it will take cross section as center and generate prompt circles to get into precise stakeout.

5.11 Electric Lines Survey

Electric power line survey is the specific program to survey and measure the natural environment along the designed line before the power line design and finally the handheld measured data would be converted via PC and output to the special format data of power software.

Press [Survey] -> [Electric Lines Survey] as shown in Figure 5.11-1, select an electric line from the electric lines library to stakeout.




Figure 5.11-1




Figure 5.11-2

The icons in side toolbar describe as follows:

: Electric Lines Library. Its operation is as same as that of Lines library.

: stakeout last electric line.

: stakeout next electric line.

: Display information. Set up display information, including Data storage type, Prompt Range and whether to enable automatic scaling, as shown in Figure 5.11-2. Data storage type includes Dao Heng and Si Wei two formats. Press [DEFAULT] and it can restore electric line stakeout settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

Prompt range: Taking the line as center and prompt range as spacing on both sides, it generates six parallel lines. The area within these six parallel lines is prompt range.

: collect TOPO point.

Defaulted items in bottom status bar describe as follows:

Target: The name of the stakeout line.


Point Horizontal distance: horizontal distance from current point to last collected point.


Mileage: draw a vertical line from current point, and mileage is the distance from current point to the start point \pm start point mileage.


Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.


Mileage Diff to Start: distance from current point to start point.


Mileage Diff to End: distance from current point to end point.


: calculate distance and height difference between two points. Select two points in map and it can calculate distance and height difference between these two points

: calculate distance from offset point to line and offset direction. Select three points in Map, the first two points form a line and see the third point as offset point. And it can calculate distance from the third point to the line formed by the first two points and offset direction.

: calculate offset angle and offset distance. Select three points in Map, the first two points form a line and see the third point as offset point. And it can calculate distance to start point, distance to end point, vertical distance to start point, vertical distance to end point, offset distance and offset angle.

: calculate distance. Select two points in Map, and it can calculate the total length of route between two points.

: calculate and stakeout angular bisector of J peg. Select a point from J peg on electric lines and it can calculate and stakeout angular bisector of angle between connection lines front and back.

: line offset storage. Select a point in line and it pops up setting dialog. Take selected point as base point, input distance, height difference and orientation (current point and the base point can be selected), and it can calculate coordinate of offset point and store in point library.

Electric Lines Survey steps:

1. Enter Electric Lines Survey, add electric line, select one line and start survey.
2. Record survey data. File format can be set in STAKEOUT SETTINGS, including Dao Heng and Si Wei. Data storage type can switch when project is created and is not allowed to switch once collection starts.

During operation, it only needs to select reference line as needed, press to collect TOPO point on detail points that needs collection and save survey data. Select Object type, select Pole Type, input width, angle, pole height and other items, and press [OK] to save. Then software will save these topographic information and property in survey file so as to record the information through direct selection instead of tedious code.

Press to enter into Electric Lines Survey interface and press [Add] to create a new electric line as shown in Figure 5.11-3. It sets start point and end point of the line, or set line name, start mileage, line length and start point.

Select target electric line and press [OK] to enter electric line survey interface as shown in Figure 5.11-4. According to stakeout prompt in bottom status, press to collect TOPO point or press handheld defined shortcut key to collect and save power property data as shown in Figure 5.11-5.




Figure 5.11-3




Figure 5.11-4




Figure 5.11-5

When in storage, according to current point type to select Object Type. Object Type includes: J pile (turning point stake), Z pile (straight line stake), Auxiliary point, 1 point measurement marker, 1 point road measuring river pond, 2 point road measuring river pond and 3 point measuring room.

[J pile] Turning point stake.

[Z pile] Straight line stake.

[Auxiliary point] General detail points.

[1 point measurement marker] It includes power line, communication line, optical cable, road, railway.

[1 point road measuring river pond] It's used for road, railway, river, pond and house.

[2 point road measuring river pond] It's used for 2-point measurement for road, river, pond and house. See detailed introduction in the following.

[3 point measuring room] It's used for 3-point measurement for house. See detailed introduction in the following.


A、 To collect J pile, Z pile, auxiliary point and general point it only needs to input point name and antenna height.

B、 During operation, when the road meets power lines, communication lines, optical cables and other lines, it needs to store power line type, span angle and other information so as to display in plan and sectional drawing of DaoHeng CAD. For instance, forward line encounters 220KV power line, Angle: acute angle of 45 degrees to the right, Height 30 meters, and perform storage.

C、 1 point measurement marker


The forward line encounters road, railway, river, pond, house and other objects, it can store by 1 point measurement marker.

For instance, in the forward direction, it encounters a road, Angle: acute angle of 60 degrees to the right, Width 10 meters. After selecting the point at one end of the physical object, collect and store data, and input the width in the storage dialog box. [Note]: when the back section point is not easy to measure, it can be measured at the front section point, and width is input negative value.



D、 2 point road measuring river pond

It's a second way to store span object and it can measure object width in more precision. On one end of the object collect and store data, choose 2-point measurement and it sets the point as point 1. After storage, collect and store data on the other end, and it sets the point as point 2. Select Gutter and input angle and other information to store. (Measurement sequence at both ends of the object can be arbitrary because software will automatically determine the front and back interrupt points of the object according to the line direction. It is important to note that it must first store point 1 and then point 2, which software will automatically process it without any choice by user.)



E、 3 point measuring room


When in house measurement, there are three ways, 1-point measurement, 2-point measurement and 3-point measurement.

(1) 1-point house measurement, that is to select [1 point road measuring river pond], select [House] as Gutter and input house length, width and height.

(2) 2-point measurement. It needs separative measurements in back corner point and front corner point in arbitrary sequence. Select [2 point road measuring river pond], select [House] as Gutter and input house length and height.

Note: house length can input positive or negative values. The positive and negative value of house length means: see forward direction of road as reference, house slants to the left or to the right, and left is positive and right is negative.


(3) 3-point measurement. It needs separative measurements in back corner point and front corner point in arbitrary sequence and then another measurement in auxiliary corner point. Note: auxiliary corner point must be a third, i.e. measurement sequence is first front and back corner points and then auxiliary point. Select [3 point measuring room] and input house length.



For collected power data, Geoelectron provides professional power conversion software ElectricPro. It converts project file (*.PD) into DeoHeng ORG data format through data edition.

5.12 Tower Stake

Tower stake is for engineering stakeout of four or eight reference points of tower foundation of high-voltage transmission line in electric construction.

Press [Survey] -> [Tower Stake] to enter into interface as shown in Figure 5.12-1. Select a point and press [Calculate] to enter interface as shown in Figure 5.12-2. Select its type (4-cross-section or 8-cross-section), input length and width, and press [Calculate] to acquire result as shown in Figure 5.12-3. Press [OK] to return to interface as shown in Figure 5.12-4. Select a tower and press [Stakeout], and stakeout interface as shown in Figure 5.12-5. Perform stakeout according to bottom status bar. During tower stake, it can collect tower section data and when distance shows 0 it means current point is on the selected line. Press  to collect tower point as shown in Figure 5.12-6.




Figure 5.12-1




Figure 5.12-2




Figure 5.12-3




Figure 5.12-4




Figure 5.12-5





Figure 5.12-6

Figure 5.12-7

The icons in side toolbar describe as follows:



: Topo point/Tower point switch icon.



: Floating collection key.



: Coordinate point library. Points collected by SurvX are stored in coordinate point library.




: Stakeout last coordinate.



: Stakeout next coordinate.



: The closest point, the point closest to stakeout point. (add in the toolbar in )



Display information: as shown in Figure 5.12-7, it can set stakeout settings, including Prompt Range and whether to enable automatic scaling; settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.

5.13 Elevation Control

Elevation control can calculate the design height of points within the range according to the design plane parameters, which is conducive to site leveling and earthwork calculation in the project.

Press [Survey]-> [Elevation Control], select the stakeout file and press [OK] to enter elevation control stakeout interface as shown in Figure 5.13-1.




Figure 5.13-1

Figure 5.13-2

Figure 5.13-3

The icons in side toolbar describe as follows:



: Elevation Control library interface as shown in Figure 5.13-2. Press [Add] as shown in Figure 5.13-3 and it can create a new elevation control. Data type includes import triangulation file, triangulation, two points area and one point area. Select item in list and it can delete and edit the selected item. Press [Import] and it can import *.TIN file. *.TIN file is a comprehensive file formed by all triangulation, two points area and one point area.

Elevation control steps:

(1) Enter Elevation Control library, press [Add] to create triangulation, two points area and one point area or import triangulation file as engineer design required.

A. To create a one point area, it needs to input a point coordinate (x, y, h), xGrade and yGrade. Coordinate and xGrade and yGrade form a plane.

B. To create a two points area, it needs to input two point coordinates with same height and Grade which together with two points forms a plane. Taking connection line of two points as boundary (starting from the point with elevation), when grade is positive, right elevation is larger than h and left elevation is smaller than h; when Grade is negative, on the contrary, right elevation is smaller than h and left elevation is larger than h.

C. To create a triangulation, input three point coordinates (x, y, h) and three points form a plane.

(2) Press [OK] to return to Elevation Control library, select stakeout target (triangulation plane), press [OK] to enter stakeout interface as shown in Figure 5.13-1. If current point is in design plane projection, it can view elevation, design height (according to design plane) and cut and fill. Perform site leveling as engineer design required.

5.14 Curve Stakeout

Curve Stakeout is a simple line stakeout tool. Software provides three types of curves, namely straight line, circle and curve. Curvature and radius of any point on circle are the same. Curvature and radius of any point on curve are changing.

Press [Survey] -> [Curve Stakeout], select a line from Curve Stakeout list to stakeout as shown in Figure 5.14-1.




Figure 5.14-1




Figure 5.14-2




Figure 5.14-3

The icons in side toolbar describe as follows:



: Curve Stakeout list as shown in Figure 5.14-2. Press [Select] to enter Curves Library as shown in Figure 5.14-3. Press [Add] and it can create Straight line, Circle (known offset angle and intersection), Circle (known coordinates and radius), Circle (known three coordinates) and Curve as shown in Figure 5.14-4. Press [Import] and it can import curve file in *.SC format. Select a curve and press [Edit] and it can edit the selected curve parameters. Press [Map] and it can view the drawn graph as shown in Figure 5.14-5. Press [Delete] and it can delete the selected curve.




Figure 5.14-4




Figure 5.14-5

↑ : Stakeout last coordinate.

↓ : Stakeout next coordinate.

Ⓐ : Add stake. It can add stake on stakeout curve according to mileage during stakeout curve.

⚙ : Display information.

📍 : collect TOPO point.

Stakeout curve steps:

- (1) Enter Curve Stakeout list.
- (2) Press [Select] to enter Curves Library and create curve or import curve file.

Parameter settings for new line are as follows:

Straight line: set Road Name, Mileage, Start Point and End Point.

Circle (known offset angle and intersection): set Name, Radius, Mileage, Corner, Intersection Point and Reference type (Reference Angle and Start Point coordinates). Corner: turning angle of line.

Circle (known coordinates and radius): set Name, Radius, Mileage, Center Point, Start Point and End Point. Center point: connection line of start point and end point, and turn left represents center point is in the left of line and turn right represents center point is in the right of line.



Circle (known three coordinates): set Name, Mileage, Start Point, Second Point and End Point.

Curve: set Name, Radius, Gradual Curve, Mileage, Corner, Intersection Point and Reference Type (Reference Angle and Start Point coordinates).

(3) Select target curve, press [OK], set Calculation mode (Calculate by integer number or Calculate by integer distance) and Interval, and press [OK] to return to Curve Stakeout list. In list it displays main points of the curve (QD、QZ、ZD、JD、HH) and coordinates and mileage according to interval settings.

(4) Select one point in Curve Stakeout list and press [OK] to enter stakeout interface as shown in Figure 5.14-1. According to interval settings, it displays mileage at the corresponding position of the line. When the distance between stakeout point and current point is less than 3 meters, it will enter into precise stakeout, and stakeout according to arrow direction and prompt in bottom status.

(5) Press  to add stake on stakeout curve.

(6) The adjacent stakeout points in the points library can be switched automatically by  and  keys.

5.15 Existing Stakeout

Existing stakeout is essentially the reversal process of line stakeout. Line stakeout is to stakeout the designed line to the field, and stakeout the line according to calculated line elements, length and azimuth. And existing lines stakeout is to survey and map out the existing roads of in detail, and then based on the data of surveying and mapping to calculate the starting point of linear range, azimuth, length, starting point and end point coordinates and other elements, in order to modify or design based on the data.

This function is usually used to collect center point of line in field. The center points are connected into polylines and the parameters of each line can be viewed in the line library. The section can also be measured.

Press [Survey]-> [Existing Stakeout] and select an existing line to stakeout as shown in Figure 5.15-1.




Figure 5.15-1




Figure 5.15-2

The icons in side toolbar describe as follows:

- : Stake Existing Lines.
- : stakeout last line.
- : stakeout next line.
- : connect end point and current point of line.
- : display information.
- : collect point.

Existing stakeout steps:

- (1) Enter Stake Existing Lines and set start line or import line files.
- (2) Select target line and press [OK] to enter stakeout interface as shown in Figure 5.15-1. The normal line is generated at the center point, which is conducive to measuring cross section. The vertical line of normal line is formed by overturning the front point, which can help to distinguish the direction.
- (3) Measure cross section of mileage at current point according to line mileage, line offset, horizontal distance and vertical distance in bottom status.
- (4) Press to collect data at current coordinate, that is, cross section.

(5) Press to connect end point and current point of stakeout line as shown in Figure 5.15-2. Press Stake Existing Lines and it can view parameters of connection line.

(6) Move current point and repeat step 4 and 5 until complete all existing line stakeout.

(7) The adjacent center points can be switched automatically by and keys to measure cross section.

5.16 Railway Stakeout

Press [Survey]-> [Railway Stakeout], select a road in Roads Library and press [OK] to enter line centerline stakeout interface as shown in Figure 5.16-1. Before measurement of longitudinal section of railway bridge, it must perform line centerline stakeout. Before measurement of longitudinal section of road bridge, it must design and stakeout road data file.




Figure 5.16-1




Figure 5.16-2




Figure 5.16-3

: Bridge management library. As shown in Figure 5.16-2, it includes Add, Edit, Delete, Import, Export and OK operation. Press [Add] to enter interface as shown in Figure 5.16-3, set coordinate A and B, and it can automatically calculate intersecting mileage, intersecting angle and other parameters. And then press [OK] to create a new bridge section. Select any bridge section and press [Edit] and it can edit every parameter. Press [Delete] and it can delete the selected bridge section. Press [Import]/[Export] and it can import/export bridge file in *.XDM format.

: Display information. Set up display information, including Prompt Range, Automatic scaling, Display key point, Assistant line, Road thickness and Limit mileage range, as shown in Figure 5.9-4. Press [DEFAULT] and it can restore changed settings. Settings for [TOPO POINT], [INFORMATION BAR] and [TOOLBARS] are the same as that of Point Survey.




Figure 5.16-4




Figure 5.16-5

: collect TOPO point. Its interface is shown in Figure 5.16-5.


Data type: Vertical section point, Intersect point, Adjacent point and Adjacent points.

Vertical section point: point type for longitudinal section stakeout.

Intersect point: point type for measurement of intersecting angle and intersecting point mileage during longitudinal section measurement.

Adjacent point and Adjacent points: point type for elevation measurement of nearby dam top, beam bottom, existing piers, flood water level points and other design relative points or point system position during longitudinal section measurement. In measurement, point type should be adjacent point. In point system measurement, point type of all points except the first point (point type as adjacent point) should be adjacent point system.

[Two point fixed line]: in line stakeout, according to site conditions, it measures two points to determine the cross section on stakeout cross section direction. These two points should measure the left one at first and then the right one. They also can be on one side or on either side of road. Image as shown in the following figure:




There are several ways to measure the points: point A and B; point C and D; point B and C.

[Two point intersects] and [Three point intersects]:

Measure intersecting angle and intersecting point mileage of intersecting railways, roads or rivers during cross section survey. In measurement it only needs to measure two points on one side of intersecting building to determine intersection angle and intersection point mileage of intersecting building and line. And then measure one point on the other side of intersecting building to determine the width of building and intersection point mileage of the measured side and line (it can directly input width).

Measurement step:

1. When measuring only two points, press [Two point intersects] to calculate angle. If the width is known, it can input directly. If the width is unknown, then width is not necessary to input.
2. When measuring three points, measure two points on one side of the intersection object and one point on the other side. When measuring the third point, press [Three point intersects] to calculate the angle and width.



Measure method sketch map

: Measure point. Culvert measurement is in some positions cannot get GPS satellites fixed, to measure a datum point in position can get fixed solution and measure distance and elevation from datum point to the unknown point by measurement type, then to calculate coordinate and elevation of the unknown point by software. This can help measure some blind spots that GPS cannot measure. Press to collect a Datum point as shown in Figure 5.16-6, and press [OK] to enter measure point interface as shown in Figure 5.16-7.




Figure 5.16-6




Figure 5.16-7

Number of scales: number of point continuous measurement. When in continuous measurement, it needs to be based on previous measure point and measure type should be same.

Measure type: [Measure vertical section] includes Mileage difference and Elevation difference; [Direct addition] includes Mileage, Horizontal distance and Elevation.

Measure direction: [Measure the left] is small mileage; [Measure the right] is big mileage.

Defaulted items in bottom status bar describe as follows:

Target: The name of the stakeout line.

H: The height of current point.

Mileage: Draw a vertical line from current point to stakeout line, and mileage is the distance from the vertical point to the start point.

Offset: Draw a vertical line from current point to stakeout line, and offset is the distance from foot point to current point. When current point is on the left in the direction of line, offset is negative; when current point is on the right in the direction of line, offset is positive.



Horizontal distance: Draw a vertical line from current point to cross section, and Horizontal distance is the distance from foot point to intersection of cross section and road.

Vertical distance: Draw a vertical line from current point to cross section, and Vertical distance is the distance from foot point to current point. "To Less" means that if you want to reach the target peg, the distance to the direction of the small mileage.

5.17 Survey Range Settings

Survey range settings is a prompt settings of survey area for the purpose of surveyor's understanding of the working area.

Press [Survey] -> [Survey Range Settings] to enter interface as shown in Figure 5.17-1, which displays point list.

Generally, survey area set up needs at least three points. As shown in Figure 5.17-2, press [Add] to set up Point Coordinates. It can press  to acquire current coordinate, or press  select from point library or input manually. After point setting, press [OK] to return to previous interface, and press [OK] to display the survey range with red line in Survey interface as shown in Figure 5.17-3. Press [Select] to select points in Points Library to form survey range. Press [Import] and it can import coordinates files (*.dat, *.txt, *.csv).




Figure 5.17-1




Figure 5.17-2




Figure 5.17-3

Select any coordinate point and press [Edit] to edit the point information.

Press [Delete] and it will pop up a prompt as shown in Figure 5.17-4 and press [OK] to delete the point.

Press [Move up] and [Move down] to move the point.

Press [Preview Map] and it can show graph formed by points in list as shown in Figure 5.17-5. And press [CAD] to enter CAD interface as shown in Figure 5.17-6.




Figure 5.17-4




Figure 5.17-5




Figure 5.17-6

5.18 Layers Settings

Layer settings of SurvX is same as that of CAD used on PC, which sets up and edits imported CAD layer. And it also supports to import *.shp layer in ArcGIS data format.

Press [Survey] -> [Layers Settings] to enter interface as shown in Figure 5.18-1. Layer is divided into CAD LINE and BACKGROUND LAYER.

CAD LINE: interface as shown in Figure 5.18-1. Press [NEW LAYER] as shown in Figure 5.18-2, input Layer Name, select color, set whether set up as a work layer, whether visible and whether lock. Press [layer] and it can delete layer or rename it.

: work layer. Only one layer is work layer.

: layer is visible.

: layer is locked. Locked layer cannot be deleted.




Figure 5.18-1




Figure 5.18-2




Figure 5.18-3

BACKGROUND LAYER: interface as shown in Figure 5.18-3. It includes five operations, namely ADD, EDIT, MOVE UP, MOVE DOWN, DELETE.

Press [ADD] and it can import layer. It supports *.shp (ArcGIS data type) and *.dxf (AUTOCAD drawing exchange file) files. When importing layer, it can view layer properties. As shown in Figure 5.18-4, it can set Contour Color, Fill Color, whether Display Label, Property, Text Color, whether is Visible and whether is Selectable. Press [Boundary] and it can check layer's boundary as shown in

Figure 5.18-5. Multiple layers can be overlapped. Layers can be chosen to Edit, Delete, Move up and Move down. It can view imported layers in Survey interface after Layer settings, as shown in Figure 5.18-6.




Figure 5.18-4




Figure 5.18-5




Figure 5.18-6

Chapter 6 Tools

6.1 Site Calibration

In general, GPS receiver output data is WGS-84 latitude and longitude coordinates. The coordinates need to be converted to the construction measure coordinates, which requires software to calculate and configure coordinate conversion parameters. Site calibration is the main tool to complete this conversion.

Press [Tools]-> [Site Calibration] to enter into interface as shown in Figure 6.1-1. It contains Add, Edit, Delete, Calculate, Import, Export and Options operation.




Figure 6.1-1







Figure 6.1-2

Press [Add] to enter into interface as shown in Figure 6.1-2.

There are two ways to set the know point coordinates: one is to press  to get coordinates from the points library, the other one is to input name, northing, easting and elevation directly. Set the known coordinate to complete inputting point coordinate in first coordinate system.

Then set WGS84 geodetic coordinate. There are three ways to set WGS-84 geodetic coordinates: the first one is press  to collect point, the second one is to press  to get coordinates from the points library, and the third one is to input name, northing, easting and elevation directly. Then it completes inputting first WGS-84 geodetic coordinate. Set whether to use horizontal control and vertical control, and then press [OK] to complete first group of

coordinates. The remaining coordinates can be added in this way, until all the coordinates which are participated in the parameter calculation have been added.

Select a coordinate in [Site Calibration] and press [Edit], you can edit the parameters of this point. Then press [OK] to save the changes.

Select a coordinate in [Site Calibration] and press [Delete], then all the data about this point could be deleted from Site Calibration.

Press [Import] to import pre-edited *.COT file and *.LOC file of SurveCE, which is convenient to coordinate input.

Press [Export] to export the coordinates in Site Calibration in *.COT file. When you need to use these coordinates next time, you can import and don't need to re-input.

Press [Options] to enter interface as shown in Figure 6.1-3.




Figure 6.1-3




Figure 6.1-4

Convert Method: it includes [Horizontal correction+ Elev_correction], [Horizontal Adjustment+ Vertical Adjustment], [Seven parameter + Horizontal correction + Elev_correction] and [Seven Parameter]. Horizontal correction includes Horizontal Adjustment and Four Parameter. Elevation correction includes height fitting and vertical adjustment.

Horizontal correction Model: it includes [Horizontal Adjustment] and [Four Parameter]. Horizontal Adjustment is defined format of Situoli. Four Parameter is suitable for four parameter compatible format like HI-TARGET.

Vertical Control: it includes [Automatic Decision], [Weighted Average], [Plane Fitting], [Surface Fitting] and [Vertical Adjustment]. Horizontal Accuracy Limit and Vertical Accuracy Limit could be changed as needed.

After all the coordinates are inputted, press [Calculate] to acquire the GPS parameter report as shown in Figure 6.1-4. Press [Apply], it will refresh the data in the coordinate point library. If the result is not applied, press return key upper left, it will return to Site Calibration interface. To ensure whether the calculation results are accurate or reliable, it can check with other known points.

6.2 Coordinates Converter

Press [Tools]- [Coordinates Converter] to enter interface as shown in Figure 6.2-1. Set up source coordinate and there are three ways to input coordinate: 1. Press to collect point; 2. Press to select from coordinate point library; 3. Directly input point name and coordinate value. Select Transform type (BLH or xyh), input coordinates, and press [Transform] to accomplish coordinate conversion and check result as shown in Figure 6.2-2. If it needs to save the converted coordinates, press [OK] and input the point name to save it to the coordinate library as shown in Figure 6.2-3.




Figure 6.2-1




Figure 6.2-2




Figure 6.2-3

6.3 Angle Converter

Press [Tools]-> [Angle Converter] as shown in Figure 6.3-1. It includes 5 angle formats, namely dd(Decimal), dd.mmssss, dd:mm:ss.ssss, dd:mm:ss.ssss''and Radian.

The conversion goes in the following sequences:1. select input angle format; 2. input angle; 3. check result.

For instance, select angle format as dd (Decimal), input angle 23.25, press [Calculate] and the result is as shown in Figure 6.3-2.




Figure 6.3-1




Figure 6.3-2

6.4 Perimeter and area

Press [Tools]-> [Perimeter and area] to enter interface as shown in Figure 6.4-1. In List it displays points in list, and in Preview Map it displays graph formed by points in list.




Figure 6.4-1




Figure 6.4-2




Figure 6.4-3

Press [Add] to enter interface as shown in Figure 6.4-2. At least 3 coordinates need to set up to calculate perimeter and area. To add points, it can press to acquire current coordinate, or press select from point library or input manually. After point setting, press [OK] to return to previous interface, and press [Calculate] to calculate perimeter and area of the graph formed by points as shown in Figure 6.4-3.

Points can be selected to Edit, Delete, Move Up and Move Down. As shown in Figure 6.4-4, Import, Export, Delete, Move Up and Move Down need to show when press .

Press [Select] and it can select points from Points Library as shown in Figure 6.4-5. It also supports Select All.

Press [Import] to enter interface as shown in Figure 6.4-6, choose import coordinates file (*.cvs, *.dat and *.txt) and Distance Unit (Meter, US Survey and International Feet) and press [OK] to find the file and press [OK] to import file and return to List or Preview Map interface.




Figure 6.4-4




Figure 6.4-5




Figure 6.4-6

6.5 COGO Calculation

Press [Tools]-> [COGO Calculation] to enter interface. According to the known coordinates, it can figure out position relations between point and point as well as between point and line. It includes Coordinate inverse calculation, Point line calculation, Vector, Two Lines Angle and other calculation, which will be introduced in the following. The following three icons in COGO Calculation mean:

: store calculation point.

: acquire current coordinate.

: Points Library.

There are three ways to set points: 1. extract coordinates from Points Library; 2. acquire current GPS coordinates; 3. directly input values of Northing, Easting and Elevation.

Calculation result in COGO calculation can be stored in Points Library with press on .

6.5.1 Coordinate inverse calculation

As shown in Figure 6.5-1, set Start Point A and End Point B, and press [Calculate] to check the result of Plane distance, Azimuth, Elevation difference, Ratio of slope and Vector, as shown in Figure 6.5-2.




Figure 6.5-1




Figure 6.5-2

6.5.2 Point line calculation

As shown in Figure 6.5-3, set Start Point A, End Point B and Offset Point C, and then press [Calculate] to check the result of Start distance, End distance, Start Vertical Distance, End Vertical Distance, Offset Distance and Offset Angle as shown in Figure 6.5-4.




Figure 6.5-3




Figure 6.5-4

6.5.3 Vector

As shown in Figure 6.5-5, set Start Point A and End Point B, and then press [Calculate] to check the result as shown in Figure 6.5-6.




Figure 6.5-5




Figure 6.5-6

6.5.4 Two Lines Angle

As shown in Figure 6.5-7, set Start Point A, End Point B, Start Point C and End Point D, and then press [Calculate] to check the result as shown in Figure 6.5-8.




Figure 6.5-7




Figure 6.5-8

6.5.5 Intersection calculation

As shown in Figure 6.5-9, set Point A, Point B, Point C and Point D, and then press [Calculate] to obtain the point coordinates as shown in Figure 6.5-10.




Figure 6.5-9




Figure 6.5-10

6.5.6 Resection

As shown in Figure 6.5-11, set Line L1, L2, Point A and Point B, and then press [Calculate] to obtain the point coordinates as shown in Figure 6.5-12.




Figure 6.5-11




Figure 6.5-12

6.5.7 Forward intersection

As shown in Figure 6.5-13, set Angle α , β , Point A and Point B, and then click [Calculate] to obtain the point coordinates as shown in Figure 6.5-14.




Figure 6.5-13




Figure 6.5-14

6.5.8 Coordinate positive calculation

As shown in Figure 6.5-15, set Line L1, Angle α , Point A and Point B, and then press [Calculate] to obtain the point coordinates as shown in Figure 6.5-16.




Figure 6.5-15




Figure 6.5-16

6.5.9 Offset point calculation

As shown in Figure 6.5-17, set Line L1, Angle α and Point A, and then press [Calculate] to obtain the point coordinates as shown in Figure 6.5-18.




Figure 6.5-17




Figure 6.5-18

6.5.10 Equal point calculation

As shown in Figure 6.5-19, set Start Point A and End Point B, and Number of segmentation, and then press [Calculation] to obtain n-1 coordinates as shown in Figure 6.5-20.




Figure 6.5-19




Figure 6.5-20

6.6 Calculator

This function is for the convenience of some simple data calculation.



Figure 6.6-1




Figure 6.7-1

6.7 External Radio configuration (not support KOLIDA receiver now)

Press [Tools]-> [External Radio configuration] to enter interface as shown in Figure 6.7-1. Connection mode for SurvX on handheld are Bluetooth and serial port, and for SurvX on PC is only Bluetooth.

Select [Serial Port] as shown in Figure 6.7-1, connect external radio and handheld by GK-186 cable, and then select serial port and baud. Press [Connect] and it would prompt connection fails if connection fails while it would appear [Settings] if connection succeed.

Select [Bluetooth] as shown in Figure 6.7-2, press [Search] to search external radio Bluetooth, select the Bluetooth and press [Connect]. When connection succeeds, [Search] would turn to be [Settings].




Figure 6.7-2




Figure 6.7-3




Figure 6.7-4

Press [Settings] to enter interface as shown in Figure 6.7-3.

Press [Parameter setting] to enter interface as shown in Figure 6.7-4, and press [Get] to obtain parameters of current connected external radio, which can be user-defined. Press [Settings] and then the parameters are set.

Press [Channel detection] as shown in Figure 6.7-5. Channel test needs external radio antenna. Press [Help] as shown in Figure 6.7-6 and it can view channel test report. As shown in Figure 6.7-7, input acquired frequency 439 and press [Query], and the result saying weak represents the channel is accessible. Press [Check] and it can acquire default frequency low noise signal intensity as shown in Figure 6.7-8.




Figure 6.7-5




Figure 6.7-6




Figure 6.7-7




Figure 6.7-8




Figure 6.7-9




Figure 6.7-10

Press [Equipment information] to enter interface as shown in Figure 6.7-9, and press [Get] and it can view settings information of connected external radio.

Press [Temperature control] to enter interface as shown in Figure 6.7-10, and press [Get] and it can view temperature control of connected external radio. It can modify temperature control information as needed, and press [Settings] to successfully modify temperature control information.

Notes: 1. Temperature threshold range [-100~1000]Celsius degree.

2. Power gain range [-60~60]dB.

3. Temperature threshold for first order must be smaller than that of two stage.

Press [Radio control] to enter interface as shown in Figure 6.7-11, it can change baud of serial port. Select baud and press [Change] and it can successfully change serial port baud of external radio. Press [Reboot] and it can reboot external radio. Press [Off] and it can switch off external radio. Press [Restore frequency table] and it can restore the changed frequency table to its defaulted settings. Press [Reset] and it can eliminate all user-defined information for external radio.

Press [Firmware update] to enter interface as shown in Figure 6.7-12, select *.bin firmware file and it would display firmware file information. After information confirm, press [Update] to




Figure 6.7-11




Figure 6.7-12

6.8 Station Refresh

Station refresh is usually used when data is collected without Site Calibration and after collection it needs to calibrate data of a certain period. Press [Tools]-> [Station Refresh]to enter into interface as shown in Figure 6.9-1. Press [Marker Point Calibration] to acquire x, y, h values and press [Refresh]. In the interface as shown in Figure 6.9-2, repress [Refresh] and enter into interface as shown in Figure 6.9-3. Select Refresh Date, Start Time and End Time and press [Refresh] to calibrate data of the period as shown in Figure 6.9-2.




Figure 6.9-1



Figure 6.9-2




Figure 6.9-3

Chapter 7 Total Station

Connect SurvX to total station and set total station in distance measurement mode, and it can control total station. The following introduces operation in detail.

7.1 Communication

Press [Device]-> [Communication], select [Total Station] as Device Type as shown in Figure 7-1. Make: Stonex, KOLIDA (taking Stonex as example); Model: R1+(Stonex), KTS400(KOLIDA); Communication Mode: Bluetooth, Serial port (taking Serial port as example) as shown in Figure 7-2. Please note that Baud Rate should be the same as that of Total Station configuration.




Figure 7-1




Figure 7-2

7.2 Height

Press [Survey]-> [Point Survey] to enter interface as shown in Figure 7-3. Press to enter interface as shown in Figure 7-4 and set Instrument height and Prism height. Reflector includes Prism, Reflectorless and Sheet. Title bar will display current reflector in different icons for user to know current settings.



Prism: It needs to input Prism height, Instrument height and Prism Constant. Prism constant is divided into two types. Usually Chinese prism is -30mm and international prism is 0mm.



Reflectorless: It applies to distance measurement where it is not suitable to place a reflection prism or reflector, such as measurement for cliffs, rock walls and other landslides, deformation measurement and tunnel construction.



Sheet: Using sheet in distance measurement, please note that signal will weaken as distance become far. It's better to measure in good weather and light vision. And there may be deviation in height measurement, so it should measure for several times to acquire average value.




Figure 7-3




Figure 7-4

7.3 Measure Mode

SurvX provides 7 measure modes for total station.



Press to enter interface as shown in Figure 7-5. The following introduces measure modes in detail.



Figure 7-5





Figure 7-6

● Sideshot (polar coordinate method): In measurement, it needs to set up station at first and then measure distance and angle to calculate another coordinate. Taking point stakeout as example, it needs to find the stakeout point position, press [Sideshot] as shown in Figure 7-6 and press  to collect points as shown in Figure 7-7. In Figure 7-6, triangle represents current coordinate and it doesn't coincide with stakeout point. Adjust total station and re-collect point until collecting point coincide with stakeout point, i.e. device is on stakeout point as shown in Figure 7-8.




Figure 7-7





Figure 7-8

● Resection: With multiple known points, only measure angle or measure angle and distance to calculate the unknown points.

For instance, set station on the unknown point (P), with three known point (A, B, C) and two angles (α , β) to calculate the unknown point (P), as shown in the following figure:



Press [Resection] to enter interface as shown in Figure 7-9, press [Add] to enter interface as shown in Figure 7-10, select point A or B or C and press [OK] to add three points involved in calculation as shown in Figure 7-11. Select point A, adjust total station to measure point A and press [Observe Dis.] to acquire distance PA by total station measurement as shown in Figure 7-12. Repeat the steps to acquire distance PB and PC, and press [Calculate] as shown in Figure 7-13 to calculate point P coordinate.




Figure 7-9




Figure 7-10




Figure 7-11




Figure 7-12





Figure 7-13

● Opposite side

The principle of opposite side measurement is as shown in the following figure. It includes horizontal distance, vertical distance, slope distance and slope between measured station and target point, and between target points. Any target point can be set as new station.



Press [Opposite side] to enter interface as shown in Figure 7-14, press [Observe] to acquire position of target point A, adjust telescope to target point B, press [Opposite] to acquire calculation result as shown in Figure 7-16. Press [New station] and it can set last measured point B as new starting point, so when target point is point C, it calculates distance BC. If it doesn't press [New station], when target point is point C, it calculates distance AC.

| ← Opposite side | |
|---------------------|-------------|
| Result | |
| Slant distance | 0.000 |
| Heigh Error | 0.000 |
| Horizontal distance | 0.000 |
| Slope | 0.000% |
| Measure | |
| HA | 9°40'44" |
| VA | 58°31'44" |
| Opposite | New station |
| Observe | |

Figure 7-14

| ← Opposite side | |
|---------------------|-------------|
| Result | |
| Slant distance | 0.000 |
| Heigh Error | 0.000 |
| Horizontal distance | 0.000 |
| Slope | 0.000% |
| Measure | |
| HA | 9°40'44" |
| VA | 58°31'44" |
| Opposite | New station |
| Observe | |


Figure 7-15

| ← Opposite side | |
|-----------------|-------------|
| Slope | 0.000% |
| Measure | |
| HA | 30°24'01" |
| VA | 59°36'43" |
| SD | 2.819 |
| HD | 2.432 |
| HI | 1.530 |
| HT | 1.400 |
| Opposite | New station |
| Observe | |

Figure 7-16

● Remote height

The principle of remote height is as shown in the following figure. Taking power line measurement as example, method is: at first place the prism directly below power line, measure the prism position, raise telescope to the target and the device screen will automatically display height from ground to target point.



Press [Remote height] to enter interface as shown in Figure 7-17, press [Observe] as shown in Figure 7-18 to measure prism position, press [High] and set prism height, raise telescope to target point, press [Remote height] to acquire calculation result.

| Remote height | |
|---------------|------|
| Result | |
| Remote height | 0.0 |
| Measure | |
| HA | 0.0 |
| VA | 0.0 |
| SD | 0.0 |
| HD | 0.0 |
| HI | 0.0 |
| Remote height | High |
| Observe | |

Figure 7-17

| Remote height | |
|---------------|-----------|
| Remote height | 0.000 |
| Measure | |
| HA | 9°28'45" |
| VA | 58°23'27" |
| SD | 2.742 |
| HD | 2.742 |
| HI | 1.530 |
| HT | 1.400 |
| Remote height | High |
| Observe | |


Figure 7-18

| Remote height | |
|---------------|-----------|
| Remote height | 2.270 |
| Measure | |
| HA | 6°58'50" |
| VA | 45°20'28" |
| SD | 2.081 |
| HD | 2.081 |
| HI | 1.530 |
| HT | 1.400 |
| Remote height | High |
| Observe | |

Figure 7-19

● Horizontal Angle Offset

The principle of Horizontal Angle Offset is as shown in the following figure. When it's hard to directly place prism, such as in the center of tree, Horizontal Angle Offset is very useful. It only needs to place prism on point P with same distance to device as that of target point, set device height/target height and perform Horizontal Angle Offset and it can acquire coordinate AO in the center of measured object.



Press [Horizontal Angle Offset] to enter interface as shown in Figure 7-20, press [Observe Dis.] as shown in Figure 7-21 to acquire prism position, adjust telescope to target point, press [Observe Angle] to acquire calculation result as shown in Figure 7-22. It also can firstly observe angle and then distance. Press [Save] and it can save the point coordinate.

| | Angle | Distance |
|----|----------|----------|
| HA | 0°00'00" | 0°00'00" |
| VA | 0°00'00" | 0°00'00" |
| SD | - | 0.000 |
| HI | 1.530 | 1.530 |

Figure 7-20

| | Angle | Distance |
|----|----------|-----------|
| HA | 0°00'00" | 9°40'16" |
| VA | 0°00'00" | 58°29'25" |
| SD | - | 2.750 |
| HI | 1.530 | 1.530 |

Figure 7-21

| | Angle | Distance |
|----|----------|-----------|
| HA | 0°00'00" | 6°50'32" |
| VA | 0°00'00" | 45°28'55" |
| SD | - | 2.087 |
| HI | 1.530 | 1.530 |

Figure 7-22

● Distance Offsets

The principle of Distance Offsets: to calculate single distance eccentric point, firstly input offsets of front, back, left and right, measure the target point and software automatically calculate eccentric point.

Press [Distance Offsets] and total station will collect a point at first. As shown in Figure 7-23, input the backward, left, and right offset distance from the device perspective, press [Observe Again], measure target point as shown in Figure 7-24 and software will automatically calculate eccentric point. Press [Save] and it can save the point coordinate as shown in Figure 7-25.

| Measure | Angle | Distance |
|---------|-------|----------|
| HA | | |
| VA | | |
| SD | | |

Figure 7-23

| Measure | Angle | Distance |
|---------|-----------|----------|
| HA | 6°50'34" | |
| VA | 45°28'55" | |
| SD | | 2.087 |


Figure 7-24

| Name | Pt1 |
|--------------------|-----------|
| Code | |
| Target height | 1.4m |
| Detail Information | |
| Northing | 1002.4457 |
| Easting | 999.3224 |
| Elevation | 51.5933 |
| HA | 6°50'34" |
| VA | 45°28'55" |

Figure 7-25

● Circle Offset

The principle of Circle Offset is as shown in the following figure. Place prism on point P1, P2, P3 and collect their coordinates and it can calculate coordinate P0.



Press [Circle Offset] to enter interface as shown in Figure 7-26, press [A Direction], measure target point P2 as shown in Figure 7-27, press [B Direction], measure target point P3 as shown in Figure 7-28, press [Center HDis.], measure point P1 as shown in Figure 7-29, and software will automatically calculate coordinate P0. Press [Save] and it can save the point coordinate as shown in Figure 7-30.

| Circle Offset | |
|---------------|--------|
| Result | |
| Radius | |
| Center North | |
| Center East | |
| Center Hight | |
| A Direction | |
| B Direction | |
| Center HDis. | |
| Save | Cancel |

Figure 7-26

| Circle Offset | |
|---------------|----------|
| Result | |
| Radius | 0.0 |
| Center North | 0.0 |
| Center East | 0.0 |
| Center Hight | 0.0 |
| A Direction | 0°00'00" |
| B Direction | |
| Center HDis. | 0.000 |
| Save | Cancel |

Figure 7-27

| Circle Offset | |
|---------------|----------|
| Result | |
| Radius | 0.000 |
| Center North | 1000.000 |
| Center East | 1000.000 |
| Center Hight | 50.000 |
| A Direction | 0°00'00" |
| B Direction | 0°00'00" |
| Center HDis. | 0.000 |
| Save | Cancel |

Figure 7-28




Figure 7-29





Figure 7-30

7.4 Orientation setup

Press [Orientation setup ] to enter interface as shown in Figure 7-31 and set survey station point and backsight point to perform orientation. There are two ways to set backsight point: Coordinate Type and Azimuth Type. Coordinate Type needs to input Northing, Easting and Elevation of point. Azimuth Type needs to input azimuth. Taking Azimuth Type as example, as shown in Figure 7-31, input Occupy point coordinate and backsight point coordinate, press [Calculate] to check calculation result as shown in Figure 7-32, press [Observe] and total station will automatically measure distance, and result displays as shown in Figure 7-33. Press [Accept] and it applies the orientation result. Press [Observe Again] and it readjusts the total station to measure distance and acquires orientation result. This observation procedure can be repeated until satisfactory orientation result is obtained.




Figure 7-31




Figure 7-32




Figure 7-33